



USER MANUAL

MW-350 LCD



Introduction to your new product

Thank you for selecting this Weld Star Infinium product.

This product manual has been designed to ensure that you get the most from your new Weld Star product. Please ensure that you are fully conversant with the information provided paying particular attention to the safety precautions. The information will help protect yourself and others against the potential hazards that you may come across.

Please ensure that you carry out daily and periodic maintenance checks to ensure years of reliable and trouble free operation.

Please call your Weld Star distributor in the unlikely event of a problem occurring.

Please record below the details of your new Weld Star product as these may be required for warranty purposes should you require assistance or spare parts.

Date purchased _____

Purchased from _____

Model name _____

Serial number _____

(The serial number is normally located on the product packaging, top or underside of the machine)

Disclaimer

Whilst every effort has been made to ensure that the information contained within this manual is complete and accurate, no liability can be accepted for any errors or omissions.

Please note:

Products are subject to continual development and may be subject to change without notice. www.weldstar.uk

No part of this manual may be copied or reproduced by any means without the written permission of Wilkinson Star Limited.



CONTENTS

	Page
Your New Product	2
Index	3
Safety Instructions	4
General electrical and operating safety	4
PPE and Welding processes lens shade selector guide	5
Fume and welding gases and fire risks	6
The working environment, Magnetic fields and cylinder safety	7
Noise and fire awareness, hot parts and RF/LF declarations	8
Materials and their disposal	9
Package Contents and Unpacking	9
Product Overview	10
Technical Specifications	11
Description of Controls	12
Installation	17
Operation - MIG/MAG	19
Feed Roll Options	25
Operation - TIG	24
Operation - MMA	28
Guide to MIG/MAG Welding	30
Guide to TIG Welding	40
Guide to MMA Welding	48
Remote Control Socket	53
Spool Gun Operating	54
Maintenance	55
Service Schedule	55
Troubleshooting	56
Error Codes	57
Electrical Schematic	58
WEEE Disposal	59
RoHS Compliance Declaration	59
UKCA Declaration of Conformity	59
EC Declaration of Conformity	60
Statement of Warranty	61
Options and Accessories	62
Notes	63
Weld Star Contact Details	64

SAFETY INSTRUCTIONS



These general safety norms cover both arc welding machines and plasma cutting machines unless otherwise noted. The user is responsible for installing and operating the equipment in accordance with the enclosed instructions.

It is important that users of this equipment protect themselves and others from harm, or even death. The equipment must only be used for the purpose it was designed for. Using it in any other way could result in damage or injury and in breach of the safety rules.

Only suitably trained and competent persons should operate the equipment.

Pacemaker wearers should consult their doctor prior to using this equipment.

PPE and workplace safety equipment must be compatible for the application of the work involved.

Always carry out a risk assessment before carrying out any welding or cutting activity.

General electrical safety



The equipment should be installed by a qualified person and in accordance with current standards in operation.

It is the users responsibility to ensure that the equipment is connected to a suitable power supply. Consult your utility supplier if required.

Do not use the equipment with the covers removed. Do not touch live electrical parts or parts which are electrically charged. Turn off all equipment when not in use.

In the case of abnormal behaviour of the equipment, the equipment should be checked by a suitably qualified service engineer.

If earth bonding of the work piece is required, bond it directly with a separate cable with a current carrying capacity capable of carrying the maximum capacity of the machine current.

Cables (both primary supply and welding) should be regularly checked for damage and overheating.

Never use worn, damaged, under sized or poorly jointed cables.

Insulate yourself from work and earth using dry insulating mats or covers big enough to prevent any physical contact.

Never touch the electrode if you are in contact with the work piece return.

Do not wrap cables over your body.

Ensure that you take additional safety precautions when you are welding in electrically hazardous conditions such as damp environments, wearing wet clothing and metal structures.

Try to avoid welding in cramped or restricted positions.

Ensure that the equipment is well maintained. Repair or replace damaged or defective parts immediately.

Carry out any regular maintenance in accordance with the manufacturers instructions.

The EMC classification of this product is class A in accordance with electromagnetic compatibility standards CISPR 11 and IEC 60974-10 and therefore the product is designed to be used in industrial environments only.

WARNING: This class A equipment is not intended for use in residential locations where the electrical power is provided by a public low-voltage supply system. In those locations it may be difficult to ensure the electromagnetic compatibility due to conducted and radiated disturbances.

General operating safety



Never carry the equipment or suspend it by the carrying strap or handles during welding.

Never pull or lift the machine by the welding torch or other cables.

Always use the correct lift points or handles. Always use the transport under gear as recommended by the manufacturer.

Never lift a machine with the gas cylinder mounted on it.

If the operating environment is classified as dangerous, only use S-marked welding equipment with a safe idle voltage level. Such environments may be for example: humid, hot or restricted accessibility spaces.

SAFETY INSTRUCTIONS

Use of Personal Protective Equipment (PPE)

⚠ CAUTION Welding arc rays from all welding and cutting processes can produce intense, visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin.

PPE REQUIRED AT ALL TIMES

- Wear an approved welding helmet fitted with an appropriate shade of filter lens to protect your face and eyes when welding, cutting or watching.
- Wear approved safety glasses with side shields under your helmet.
- Never use any equipment that is damaged, broken or faulty.
- Always ensure there are adequate protective screens or barriers to protect others from flash, glare and sparks from the welding and cutting area.
- Ensure that there are adequate warnings that welding or cutting is taking place.
- Wear suitable protective flame resistant clothing, gloves and footwear.
- Ensure adequate extraction and ventilation is in place prior to welding and cutting to protect users and all workers nearby.
- Check and be sure the area is safe and clear of flammable material before carrying out any welding or cutting.



Some welding and cutting operations may produce noise. Wear safety ear protection to protect your hearing if the ambient noise level exceeds the local allowable limit (e.g: 85 dB).

Welding and Cutting Lens Shade Selector Guide

Current	MMA Electrodes	MIG Light Alloys	MIG Heavy Metals	MAG	TIG	Plasma Cutting	Plasma Welding	Air Arc Gouging	Current					
10	8	10	10	10	9	11	10	10	10					
15									15					
20									20					
30	9				10		10		10	11	10	30		
40												40		
60												60		
80	10								11	11		12	10	80
100														100
125														125
150	11	11	11	12						10		150		
175												175		
200						200								
225	12	12	12	13	12	13	11	225						
250							250							
275							275							
300							300							
350							350							
400	13	14	13	14	14	14	14	400						
450								450						
500								500						

SAFETY INSTRUCTIONS

Safety against fumes and welding gases



Warning
Fumes and
Gases

The HSE have identified welders as being an 'at risk' group for occupational diseases arising from exposure to dusts, gases, vapours and welding fumes. The main identified health effects are pneumonia, asthma, chronic obstructive pulmonary disease (COPD), lung and kidney cancer, metal fume fever (MFF) and lung function changes.

During welding and hot cutting 'hot work' operations, fumes are produced which are collectively known as welding fume. Depending upon the type of welding process being performed, the resultant fume generated is a complex and highly variable mixture of gases and particulates.

Regardless of the length of welding being carried out, all welding fume, including mild steel welding requires suitable engineering controls to be in place which is usually Local Exhaust Ventilation (LEV) extraction to reduce the exposure to welding fume indoors and where LEV does not adequately control exposure it should also be enhanced by using suitable respiratory protective equipment (RPE) to assist with protecting against residual fume.

When welding outdoors appropriate RPE should be used.

Prior to undertaking any welding tasks an appropriate risk assessment should be carried out to ensure expected control measures are in place.



An example of personal fume protection

Locate the equipment in a well-ventilated position and keep your head out of the welding fume.

Do not breathe in the welding fume.

Ensure the welding zone is well-ventilated and provision should be made for suitable local fume extraction system to be in place.

If ventilation is poor, wear an approved airfed welding helmet or respirator.

Read and understand the Material Safety Data Sheets (MSDS's) and the manufacturer's instructions for metals, consumable, coatings, cleaners and de-greasers.

Do not weld in locations near any de-greasing, cleaning or spraying operations.

Be aware that heat and rays of the arc can react with vapours to form highly toxic and irritating gases.

For further information please refer to the HSE website www.hse.gov.uk for related documentation.

Precautions against fire and explosion



Caution
Risk of fire

Avoid causing fires due to sparks and hot waste or molten metal.

Ensure that appropriate fire safety devices are available near the welding and cutting area.

Remove all flammable and combustible materials from the welding, cutting and surrounding areas.

Do not weld or cut fuel and lubricant containers, even if empty. These must be carefully cleaned before they can be welded or cut.

Always allow the welded or cut material to cool before touching it or placing it in contact with combustible or flammable material.

Do not work in atmospheres with high concentrations of combustible fumes, flammable gases and dust.

Always check the work area half an hour after cutting to make sure that no fires have begun.

Take care to avoid accidental contact of the torch electrode to metal objects, as this could cause arcs, explosion, overheating or fire.

Know and understand your fire extinguishers

	Water	Foam spray	ABC powder	Carbon dioxide	Wet chemical
Wood, paper & textiles	✓	✓	✓	✗	✓
Flammable liquids	✗	✓	✓	✓	✗
Flammable gases	✗	✗	✓	✗	✗
Electrical contact	✗	✗	✓	✓	✗
Cooking oil & fat	✗	✗	✗	✗	✓

SAFETY INSTRUCTIONS

The working environment



Ensure the machine is mounted in a safe and stable position allowing for cooling air circulation.
Do not operate equipment in an environment outside the laid down operating parameters.
The welding power source is not suitable for use in rain or snow.

Always store the machine in a clean, dry space.

Ensure the equipment is kept clean from dust build up.

Always use the machine in an upright position.

Protection from moving parts



When the machine is in operation keep away from moving parts such as motors and fans.

Moving parts, such as the fan, may cut fingers and hands and snag garments.

Protections and coverings may be removed for maintenance and managed only by qualified personnel after first disconnecting the power supply cable.

Replace the coverings and protections and close all doors when the intervention is finished and before starting the equipment.

Take care to avoid getting fingers trapped when loading and feeding wire during set up and operation.

When feeding wire be careful to avoid pointing it at other people or towards your body.

Always ensure machine covers and protective devices are in operation.

Risks due to magnetic fields



Warning
Strong magnetic field

The magnetic fields created by high currents may affect the operation of pacemakers or electronically controlled medical equipment.

Wearers of vital electronic equipment should consult their physician before beginning any arc welding, cutting, gouging or spot welding operations.

Do not go near welding equipment with any sensitive electronic equipment as the magnetic fields may cause damage.

Keep the torch cable and work return cable as close to each other as possible throughout their length.

This can help minimise your exposure to harmful magnetic fields.

Do not wrap the cables around the body.

Handling of compressed gas cylinders and regulators



Danger
Compressed gas

Mishandling gas cylinders can lead to rupture and the release of high pressure gas.

Always check the gas cylinder is the correct type for the welding to be carried out.

Always store and use cylinders in an upright and secure position.

All cylinders and pressure regulators used in welding operations should be handled with care.

Never allow the electrode, electrode holder or any other electrically “hot” parts to touch a cylinder.

Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.

Always secure the cylinder safely and never move with regulator and hoses connected.

Use a suitable trolley for moving cylinders.

Regularly check all connections and joints for leaks.

Full and empty cylinders should be stored separately.

Never deface or alter any cylinder

SAFETY INSTRUCTIONS

Fire awareness



The cutting and welding process can cause serious risks of fire or explosion. Cutting or welding sealed containers, tanks, drums or pipes can cause explosions. Sparks from the welding or cutting process can cause fires and burns. Check and risk assess the area is safe before doing any cutting or welding. Ventilate all flammable or explosive vapour from the workplace.

Remove any and all flammable materials away from the working area. If necessary, cover flammable materials or containers with approved covers (following manufacturers instructions) if unable to remove from the immediate area.

Do not cut or weld where the atmosphere may contain flammable dust, gas or liquid vapour.

Always have the appropriate fire extinguisher nearby and know how to use it.

Hot parts



Always be aware that material being cut or welded will get very hot and hold that heat for a considerably long time which will cause severe burns if the appropriate PPE is not worn. Do not touch hot material or parts with bare hands.

Always allow for a cooling down period before working on material recently cut or welded. Use the appropriate insulated welding gloves and clothing to handle hot parts to prevent burns.

Noise awareness



The cutting and welding process can generate noise that can cause permanent damage to your hearing. Noise from cutting and welding equipment can damage hearing.

Always protect your ears from noise and wear approved and appropriate ear protection if noise levels are high.

Consult with your local specialist if you are unsure how to test for noise levels.

RF Declaration



Equipment that complies with directive 2014/30/EU concerning electromagnetic compatibility (EMC) and the technical requirements of EN60974-10 is designed for use in industrial buildings and not for domestic use where electricity is provided via the low voltage public distribution system.

Difficulties may arise in assuring class A electromagnetic compatibility for systems installed in domestic locations due to conducted and radiated emissions.

In the case of electromagnetic problems, it is the responsibility of the user to resolve the situation.

It may be necessary to shield the equipment and fit suitable filters on the mains supply.

LF Declaration



Consult the data plate on the equipment for the power supply requirements.

Due to the elevated absorbance of the primary current from the power supply network, high power systems affect the quality of power provided by the network. Consequently, connection restrictions or maximum impedance requirements permitted by the network at the public network connection point must be applied to these systems.

In this case, the installer or the user is responsible for ensuring the equipment can be connected, consulting the electricity provider if necessary.

SAFETY INSTRUCTIONS

Materials and their disposal



Welding equipment is manufactured with BSI published standards meeting CE requirements for materials which do not contain any toxic or poisonous materials dangerous to the operator.

Do not dispose of the equipment with normal waste.

The European Directive 2012/19/EU on Waste Electrical and Electronic Equipment states that electrical equipment that has reached its end of life must be collected separately and returned to an environmentally compatible recycling facility for disposal.

For more detailed information please refer to the HSE website www.hse.gov.uk

PACKAGE CONTENTS AND UNPACKING

Supplied within your new Weld Star Infinium product package will be the following items with each model. Use care when unpacking the contents and ensure all items are present and not damaged.

If damage is noted or items are missing, please contact the supplier in the first instance and before installing or using the product.

Record the product model, serial numbers and purchase date in the information section found on the inside front page of this operating manual.

Weld Star WS-M350 (ZXWS-M350)

WS-M350 power source only

Air cooled T36 MIG torch 4m

3m work return lead

Gas regulator and hose

USB Stick with Operating manual

Weld Star WS-M350 (ZXWS-M350-TD)

WS-M350 power source c/w drawer and trolley

Air cooled T36 MIG torch 4m

3m work return lead

Gas regulator and hose

USB Stick with Operating manual

Weld Star WS-M350 (ZXWS-M350-WC)

WS-M350 power source c/w cooler and trolley

Water cooled 501 MIG torch 4m

3m work return lead

Gas regulator and hose

USB Stick with Operating manual

Please Note: Package contents may vary depending on country location and package part number purchased

PRODUCT OVERVIEW

The Weld Star Infinium inverter multi process machine has been designed to incorporate the most advanced features and technology offering the operator a user friendly interface via the 5" LCD screen. Available as a stand alone air cooled package or fitted to a trolley with either a water cooler or storage box.

Welding process's available to the operator are as follows:

- ♦ MIG/MAG Synergic
- ♦ MIG/MAG Pulse
- ♦ MIG/MAG Dual Pulse
- ♦ MIG/MAG Standard
- ♦ LIFT TIG DC
- ♦ MMA DC



Weld Star Plasma WS-M350 Product Features:

- Advanced IGBT multi process inverter technology which is light weight and compact in design.
- The WS-M350P requires a three phase 400V AC power and is available as air cooled, water cooled and with or without a trolley.
- Welding modes include MIG standard, MIG Synergic, MIG Pulse, TIG DC (Lift TIG) and MMA.
- Many user functions such as accurate preset current and voltage adjustment, Pulse, 2T/4T and spot operation trigger modes, synergic mode, gas selection, wire diameter selection, electronic inductance adjustment and on-demand fan are available.
- With synergic MIG, welding parameters can be automatically selected based on material thickness and voltage with Synergic curves for common materials and wires.
- Job mode which allows the operator to save and recall 10 jobs within its memory.
- Designed for gas and gasless MIG welding wires.
- MIG Spool Gun connectivity.
- Built in TIG welding features such as Lift TIG, pre/post gas times, 2T/4T, slope up/down and pulse, all to ensure excellent TIG welding characteristics.
- Built in hot start arc ignition function which ensures excellent arc ignition in MMA for easier and more reliable arc starting with built in self adaptive arc force technology which maintains the optimum MMA arc conditions during operation even with long welding cables
- DC MMA suitable for a wide range of MMA stick electrodes
- Auto compensation for mains voltage fluctuation with automatic protective functions including over-current, overload etc.
- Depending on model purchased the WS-M350 is supplied with a MIG torch, gas regulator, gas hose, work return lead and clamp

TECHNICAL SPECIFICATIONS

Parameter	Unit	Weld Star WS-M350
Rated input voltage	V	AC 400V $\pm 15\%$ 50/60Hz
Rated input power	kVA	MIG 7.8 TIG 6.5 MMA 8.6
Rated input current I _{max}	A	MIG 20.7 TIG 17 MMA 22.7
Rated input current I _{eff}	A	MIG 11.3 TIG 9.3 MMA 12.4
Welding current range	A	MIG 20 ~ 350 TIG 10 ~ 350 MMA 10 ~ 350
No-load voltage	V	MIG 14V MMA 14V TIG 72V
Rated duty cycle (40°C)	%	MIG 350A @ 30% MMA 350A @ 30% TIG 350A @ 30%
Efficiency	%	85
Idle State Power	W	25
Power factor	cos ϕ	0.7
Standard	-	EN60974-1
Protection class	IP	IP23
Insulation class	-	H
Noise	db	<70
Humidity	%	<90% (20°C)
Operating temperature range	°C	-10 ~ +40
Storage temperature	°C	-25 ~ +55
MIG recommended wire size	mm	FE: 0.6/0.8/1.0 /1.2/1,6 SS: 0.8/1.0/1.2 Flux Cored 0.6/0.8/1.0/1.2 Al: 1.0/1.2
Wire reel weight/spool size	Kg/mm	5kg / 200mm and 15kg / 300mm
MMA electrode size range	mm	1.6 ~ 6.0
Overall size	mm	Power source only: 680 X 250 X 485 * Power source, cooler and trolley: 1200 X 380 X 600
Weight	Kg	Power source only: 27.9 Power source, cooler and trolley: 48.0


* Measurement taking into account the machines handle.

CONTROLS

Air Cooled package (stand alone)


Front view Weld Star WS-M350P

1. Machine carry handle
2. Protective control panel cover
3. MIG Torch connector, the connection that allows for a euro style MIG torch to be fitted
4. Control socket (see page 53 for further information)
5. '+' Positive dinse socket outlet (35/50mm)
6. 5" LCD user interface display
7. Control panel (see page 15 for further information)
8. Cooling air vent
9. TIG gas outlet (10mm)
10. '-' Negative dinse socket outlet (35/50mm)
11. MIG polarity trailing lead connector, this connection allows for the MIG gun to be connected to either positive '+' or negative '-'



Rear view Weld Star WS-M350P

12. Machine carry handle
13. Gas inlet
14. Auxiliary control socket
15. Mains power ON/OFF switch
16. Mains input cable
17. Air vent




CONTROLS

Air Cooled package with storage box/trolley


Front view Weld Star WS-M350P

1. Machine carry handle
2. Protective control panel cover
3. Torch connector, the connection that allows for a euro style MIG to be fitted
4. Control socket (see page 53 for further information)
5. '+' Positive dinse socket outlet (35/50mm)
6. Handle for storage draw
7. Storage unit c/w front sliding draw
8. 5" LCD display
9. Control panel (see page 15 for further information)
10. Cooling air vent
11. TIG gas outlet
12. '-' Negative dinse socket outlet (35/50mm)
13. MIG polarity trailing lead connector, this connection allows for the MIG gun to be connected to either positive '+' or negative '-'



Rear view Weld Star WS-M350P

14. Machine carry handle
15. Gas inlet
16. Auxiliary control socket
17. Storage unit
18. Mains power ON/OFF switch
19. Mains input cable
20. Air vent




CONTROLS

Water Cooled package with cooler/trolley


Front view Weld Star WS-M350P

1. Machine carry handle
2. Protective control panel cover
3. Torch connector, the connection that allows for a euro style MIG to be fitted
4. Control socket (see page 53 for further information)
5. '+' Positive dinse socket outlet (35/50mm)
6. Cooler coolant level display
7. Water cooler air vent
8. 5" LCD display
9. Control panel (see page 15 for further information)
10. Cooling air vent
11. TIG gas outlet
12. '-' Negative dinse socket outlet (35/50mm)
13. MIG polarity trailing lead connector, this connection allows for the MIG gun to be connected to either positive '+' or negative '-'
14. Water cooler outlet connector (to TIG torch)
15. Water cooler inlet connector (return from TIG torch)



Rear view Weld Star WS-M350P


17. Machine carry handle
18. Gas inlet
19. Auxiliary control socket (Power source)
20. Auxiliary control socket (water cooler)
21. Water cooler air vent
22. Mains power ON/OFF switch
23. Mains input cable
24. Air vent
25. Water cooler outlet connector
26. Water cooler inlet connector



CONTROLS

Side view Weld Star WS-M350P

1. Carry handle
2. Mains power cable input gland
3. Wire spool holder and tensioner:
Allows for a 15Kg (300mm dia) reel of wire to be located in place via an alignment pin and then locked in place with the locking nut.
The spool holder also has a brake arrangement to ensure correct tension of the wire, this is done by turning the central bolt with an Allen key clockwise (to tighten) or anti clockwise (to loosen)
4. Rear panel (see from page 12 for further information) and air vent
5. Protective control panel cover
6. Control panel (see lower down and from page 12 for further information)
7. Drive Assembly feed motor and gearbox (the feed motor is located behind plastic cover)
8. Upper pressure drive roll assembly: Holds the upper drive rolls in place which applies pressure to the welding wire via the installed grooved drive roll, the pressure is applied via the two drive roll tensioners which allows the correct amount of tension to be applied to the top roller assemblies to ensure good feed of the wire through the MIG torch.
9. Outlet feed adaptor: Part of the Euro outlet connector which contains the inner outlet guide which ensures smooth wire feed from the drive assembly through to the MIG torch
10. Wire feed roller and retaining nut: Secures and holds the grooved drive rolls in place
11. Inlet wire guide: The welding wire is fed through the inlet guide prior to feeding through the drive rollers



Control panel view Weld Star WS-M350P

1. Left Control button and dial
2. Central 5" colour digital screen
3. Right control button and dial
4. Control button to access options icon located in the bottom left hand of the display screen
5. Main control dial and activation button
6. Control button to access options icon located in the bottom right hand of the display screen



Please Note:

- Pressing and holding button 1 in any of the welding process selection screens will inch the wire feed motor.
- Pressing and holding button 3 in any of the welding process selection screens will activate the gas solenoid and purge the shielding gas to allow the gas flow to be accurately set.

INSTALLATION

Unpacking

Check the packaging for any signs of damage.

Carefully remove the machine and retain the packaging until the installation is complete.

Location

The machine should be located in a suitable position and environment. Care should be taken to avoid moisture, dust, steam, oil or corrosive gases.

Place on a secure level surface and ensure that there is adequate clearance around the machine to ensure natural airflow.

Input connection

Before connecting the machine you should ensure that the correct supply is available.

Details of the machine requirements can be found on the data plate of the machine or in the technical parameters shown in the manual.

The equipment should be connected by a suitably qualified competent person. Always ensure the equipment has a proper grounding.

Never connect the machine to the mains supply with the panels removed.

Output connections

Electrode polarity

In general when using manual arc welding electrodes the electrode holder is connected to the positive terminal and the work return to the negative terminal. Always consult the electrode manufacturer's data sheet if you have any doubts.

MMA welding


Insert the cable plug with electrode holder into the "+" socket on the front panel of the welding machine and tighten it clockwise.

Insert the cable plug of the work return lead into the "-" socket on the front panel of the welding machine and tighten it clockwise.

INSTALLATION

MIG welding

- Insert the welding torch (B) into the “Euro connector for torch in MIG” output socket on the front panel of the machine and tighten it into position.
- Insert the work return lead cable plug (A) into the “-” output terminal of the welding machine and tightened by rotating it clockwise.
- Ensure that the cable tail (C) the torch polarity connection cable is fitted into the “+” output terminal of the welding machine and tightened by rotating it clockwise.
- Install the welding wire on the spindle adapter.
- Connect the cylinder (H) equipped with the gas regulator (G) to the gas inlet on the back panel of the machine (E) with a gas hose.
- Ensure that the wire groove size of the fitted drive roll matches the contact tip (fitted to the MIG torch) and the welding wire size being used.
- Release the pressure arm of the wire feeder to thread the wire through the guide tube and into the drive roll groove and then adjust the pressure arm, ensuring no sliding of the wire (too much pressure will lead to wire distortion which will affect wire feeding).
- Via the user display, place the welding mode function into the MIG position.
- Press the torch trigger to feed the wire out through the torch and out via the contact tip.
- You are now ready to start MIG welding.



Gasless self shielded MIG welding

When carrying out MIG welding with gasless welding wire the welding torch polarity is reversed, so the MIG torch is '-' and the work return lead is '+'.

Follow the above procedure except for the following:

- Insert the work return lead cable plug (A) into the “+” output terminal of the welding machine and tighten by rotating it clockwise.
- Ensure that the cable tail (C) the torch polarity connection cable Insert the work return lead cable plug (A) is fitted into the “-” output terminal of the welding machine and tightened by rotating it clockwise.
- Ensure that you have turned OFF the gas supply at the cylinder.



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any persons within the welding area.

MULTIFUNCTIONAL DISPLAY WINDOW


Display Screen Explained WS-350P

Upon powering ON your 350P and boot up sequence is complete, the main menu will appear on the LCD digital screen '2' as shown right, this allows the operator to navigate the various welding processes by rotating the control dial '5' clockwise or anti clockwise and when the desired option is front and centre then you can press the dial '5' to access the chosen welding mode.

Along with the settings option you can also navigate yourself through the welding modes that include: MMA, MIG Dual Pulse, MIG Pulse, MIG Synergic, MIG Manual and Lift TIG.

Button '4' is usually associated with the icon that's circled '7' (to access option short press 4). Button '6' is usually associated with the icon that's circled '8' (to access option short press 6).

Pressing button 8 in the above screen will automatically open the memory saved screen so that you can recall a previously saved welding program, see page 19 for further information on saving and loading welding programs.



Please Note:

- Pressing and holding button 1 in any of the welding process selection screens will inch the wire feed motor.
- Pressing and holding button 3 in any of the welding process selection screens will activate the gas solenoid and purge the shielding gas to allow the gas flow to be accurately set.

As an example of navigating the menu structure, navigate to the MIG manual welding process option as shown above image, you can then either press the control dial 5 or press button 4 to enter the MIG manual welding process.

Upon pressing the control dial 5, you are now taken to the MIG manual welding process control screen, as shown below, where you can adjust (in this case being MIG Manual) the following settings:

Rotating control dial 1 adjusts the Wire Feed Speed


Rotating control dial 3 adjusts the Welding Voltage

Pressing control dial 5 will allow the operator to scroll through three welding settings:

- * Torch switch trigger mode 2T, 4T and Spot.
- * Spool-on-gun option
- * Variable Inductance control.

To access and adjust these three welding settings, press control dial '5' and you will note in the centre of the screen either trigger mode, spool gun option or inductance control will highlight in turn as you press control dial B.

To adjust a highlighted parameter, rotate control dial 5 either clockwise or anticlockwise control dial 5 to adjust selected parameter and then pressing the control dial again will store the parameter setting and automatically move to the next parameter option.



Please Note: Parameter options vary depending on welding process and other features such as torch trigger mode selected.

MULTIFUNCTIONAL DISPLAY WINDOW

Display Screen Explained WS-200P (continued)

Following on from the instructions on the previous page, if you press and release button '6' you will now enter a new screen (shown right) that allows the operator to select and adjust more advanced MIG parameter settings such as:

- Pre gas flow
- Creep Feed
- Post gas flow
- Burn back



Please Note: Depending on welding process and whether 2T or 4T torch trigger mode are selected other parameters maybe available.

Via the main welding screen, there is a vast range of parameter information available for the operator. The image right details the welding screen for MIG Dual Pulse mode which highlights the lower two bars and explains what the data represents.

Top row: material, gas and wire size.

Bottom row: trigger mode, burnback, wire feed creep speed, pre-gas and post-gas setting and the inductance setting.

The central circled area offer further welding parameters and these are accessed and adjusted by pressing to select and rotating control dial 5 to adjust.



Save and Recalling welding programs

The following information details the save and load options of welding parameters as detailed below:

Saving a welding program



While in the general welding screen (as above), long press button '1' until the screen changes to the memory save option screen (shown left).

As you will see this screen allows the operator to save his welding setup to 1 of 10 memory programs.

To save, rotate the control dial '5' to the desired program number and then press control dial '5' to save.

Loading a welding program



While in the general welding screen (as above), long press button '3' until the screen changes to the memory recall option screen (shown left).

This screen allows the operator to load previously saved welding programs.

To load/recall a program, rotate control dial '5' to the desired program number and then press and release control dial '5' to load required welding program. You will then go to the loaded welding program screen.


OPERATION - MIG/MAG



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any persons within the welding area.

MIG/MAG welding mode

MIG - Metal Inert Gas Welding, MAG - Metal Active Gas Welding, GMAW - Gas Metal Arc Welding



MIG welding was developed to help meet production demands of the war and post war economy which is an arc welding process in which a continuous solid wire electrode is fed through a MIG welding gun and into the weld pool, joining the two base materials together.

A shielding gas is also sent through the MIG welding gun and protects the weld pool from contamination which also enhances the arc.

Connect the MIG torch as shown (B), the work return lead (A) to '-' and connect the trailing lead (C) to '+' (D).

Ensure that a suitable inert gas supply is connected (E).

Switch the power switch on the back panel to "ON" (F) the machine is started with the panel display coming ON.


Via the display navigate to the welding mode options and set welding mode and select either MIG normal, MIG synergic MIG pulse or MIG double pulse depending on your application.

Open the gas valve of the cylinder (H) and adjust the gas regulator to obtain the desired flow rate (G).

Adjust via the user display the MIG settings on the machine control panel to get the correct desired welding condition of welding voltage, current etc (see page 18 and 21 for further info on the control panel display function).

Operate the torch trigger and welding can be carried out, (Note: Once the MIG torch switch is pressed, if no welding current is sensed within 5 seconds, the wire feed, gas and output voltage will stop).

The MIG wire guide to the right can vary depending on material being used, work piece thickness, welding position and joint form.




Wire Diameter (mm)	DIP Transfer		Spray Transfer	
	Current (A)	Voltage (V)	Current (A)	Voltage (V)
0.6	30 ~ 80	15 ~ 18	n/a	n/a
0.8	45 ~ 180	16 ~ 21	150 ~ 250	25 ~ 33
1.0	70 ~ 180	17 ~ 22	230 ~ 300	26 ~ 35
1.2	60 ~ 200	17 ~ 22	250 ~ 400	27 ~ 35
1.6	100 ~ 280	18 ~ 22	250 ~ 500	30 ~ 40

MIG - Gasless

The operation method is the same as the above MIG operation except there are no shielding gas used and the output polarity is reversed (this is managed with item 'C' in above image), see page 17 for further details.

MULTIFUNCTIONAL DISPLAY WINDOW - MIG MODE

Welding screen/display explained WS-M350



Upon powering ON your WS-M350 and boot up is complete, the control panels main menu will appear on the digital panel as shown above. From here the operator can navigate through the various options and welding modes which include:

Settings, MIG Pulse and Dual Pulse, MIG Synergic, MIG Standard (Manual) and Lift TIG.

In the home screen, for MIG welding process the following options are available:

- MIG Manual
- MIG Synergic
- MIG Pulse
- MIG Dual Pulse

By rotating the lower centre control dial (5) you will 'scroll' through the options and by pressing the dial you will enter either Pulse, Dual Pulse, Synergic or manual mode as shown in the examples below:



Conventional MIG welding equipment (MIG manual) run at a steady single amperage where the operator has access and controls of the wire feed speed rate and the welding voltage whereas with MIG pulsed welding the machine runs a peak and a background amperage and the unit will constantly switch between the two amperages enabling the operator to put out a lower overall heat input into the material. One of the benefits of MIG pulse includes smoother spatter free welding to help prevent blowing through thin material.

When MIG synergic welding is referred to it means that when a single setting is adjusted (voltage or material thickness) the other settings like current or wire speed change automatically.

Before selecting the required MIG process, it's at this point you have the option features of Wire Inch and Gas purge.

Pressing and holding button 1 will inch the wire feed motor.

Pressing and holding button 3 purge the shielding gas.

MULTIFUNCTIONAL DISPLAY WINDOW - MIG MODE

Welding screen/display explained WS-M350

For example, select MIG Pulse Mode which gives the operator the option to select material, gas and wire size as shown below, this selection is carried out by rotating and pressing the control dial to select the desired option.

Material selection choice is as follows:

FE - Mild Steel

Flu.Fe - Flux Cored

Ss - Stainless Steel

AlMg - Aluminium Magnesium


CuSi - MIG Brazing



Gas selection choice is:

80%Ar 20%CO2

100% CO2



Wire diameter size selection choice is as follows:

0.6mm (0.024)

0.8mm (0.032)

0.9mm (0.035)

1.0mm (0.039)

1.2mm (0.045)



Please Note: Gas and wire size options will depend on your welding process and material selection.

Once you have selected the welding setup modes as shown above and on selecting the wire diameter size, the display will change and show the below screen, which is the users main welding screen.

At this point the 2 bars along to bottom of the screen does show the operator the welding mode setup:

Material, gas and wire size along with Trigger mode, burnback time, Creep feed speed, pre-gas and post gas time.




However further welding parameters such as material thickness 2T/4T, Inductance, hot start, arc force, pulse duty and frequency have been factory preset although adjustments can be made by following the next steps.

MULTIFUNCTIONAL DISPLAY WINDOW - MIG MODE

Welding screen/display explained WS-M350

The selection and setting of advanced welding parameters can be carried out in the welding interface screen by pressing the lower right button (6) to enter the welding parameter setting interface. In this welding parameter setting interface, you will see the available parameters that can be adjusted.

By rotating the control dial (5) you will in-turn select the available parameters as required, select the parameter you wish to adjust, press the control dial (5) to enter that parameter and then you will be able to set a value for the selected parameter. Pressing the dial again saves your chosen setting and moves to the next parameter.



You will note from the image left that the selected parameter being adjusted is pre-flow gas.

The gas time is clearly shown in the middle and side bar show graphically the adjustment range.

The minimum setting (0.0) and the maximum the setting (2.0),

by rotating the lower control dial (5) clockwise or anti-clockwise allows the operator to adjust the gas time and set by pressing the control dial.

The adjustable parameters available to the operator are as follows:

Pre flow

Pre-gas is a parameter that allows the operator an adjustable gas flow time prior to striking the welding arc once the torch trigger has been pressed. This control can be used to reduce weld porosity at the start of the weld.

Post Flow

Post Gas is a parameter that offers the operator an adjustable post gas flow time once the welding arc has extinguished. This control is used to reduce weld porosity when finishing of the weld.

Burnback

Burnback control is the control which adjusts the amount of time that the MIG welding wire remains electrically energized for after the wire feed drive has stopped feeding.

Initial Feed

Creep speed, is there to enable smooth controlled arc ignition, for example if the main welding wire speed was 5 m/min, you wouldn't want the wire to come out of the tip and crash into the plate at 10 m/min as this would lead to unstable start along with spatter etc. So for example the creep speed could be set at 2 Meters/Min and then ramp up to 5 Meters/Min once the welding arc has established.

When in MIG Dual Pulse mode additional parameters are available as follows:

- Dual Pulse Frequency
- Dual Pulse Duty
- Base Current Arc Length

MULTIFUNCTIONAL DISPLAY WINDOW - MIG MODE

Welding screen/display explained WS-M350

Further welding parameters are also accessible from the main MIG welding screen and are located and highlighted in the image (right) circled within the central section of the display.

The selection welding parameters do vary depending again on which MIG welding process has been selected.

It can be noted at the bottom of the circle there are 4 indicators (1 red and 3 white dots), these indicators inform the operator that there are 4 parameters available in this section.

The highlighted red indicator refers to the shown parameter which is 'Thickness' which refers to material thickness, the parameters available are:


Torch Trigger mode,

Material Thickness

Wire Feed Speed,

Arc Length.

To access these welding parameter settings, press the control dial (5) to select the parameter as required, then rotate the dial (5) to set a value for the selected parameter. Pressing the dial again saves your chosen setting and moves to the next parameter.



2T, 4T, S4T and Spot

2T (2 stroke) 4T (4 stroke/latch) in 2T mode the weld will start and continue while the trigger is pressed. 4T mode once welding has commenced you can release the trigger and welding will continue until the trigger is activated again.

S4T gives the operator some flexibility in pressing and releasing the trigger while welding to give stepped amperage control.

Spot is a preset fixed time that the machine will weld for, with an adjustable range of 0 - 10 seconds.

Wire Feed Speed

This option allows the operator to adjust the welding settings based on wire feed speed, as you increase or decrease wire feed speed you will note that welding amperage and voltage adjust automatically.

Material Thickness

This option allows the operator to adjust the setting based on material thickness, as you increase or decrease the material thickness you will note that welding amperage and voltage adjust automatically.

Arc length

Only available in Pulse Mode is an arc length trim that controls the arc length and voltage automatically when a set of input conditions are specified. Having a longer welding arc will offer the operator a more fluid puddle or flatter the weld profile will be. Arc length in pulse mode is good for reducing spatter as a fluid weld puddle creates little to no spatter.

Inductance

Inductance is also available although only in MIG Manual and MIG Synergic mode.

Inductance in MIG welding controls the rate of current rise following the short-circuit state that is during the time when the wire is short circuiting into the weld puddle which also affects arc time also which increases or decreases the amount of time the short circuit cycle spends arcing and providing heat to the puddle. That is why when adjusting the inductance control can make the welding arc sound entirely different.

MULTIFUNCTIONAL DISPLAY WINDOW - MIG MODE

Welding screen/display explained WS-M350

Advanced welding parameters adjustment range chart can be seen below.

FUNCTION	ADJUSTABLE RANGE	MODE
Pre-flow	0 ~ 2S	2T/4T
Post-Flow	0 ~ 10S	
Burn Back	0 ~ 10	
Slow Feed	0 ~ 10	
Spot Weld Time	0 ~ 10S	Spot
Dual Pulse Frequency	0.5 ~ 3Hz	Dual Pulse
Dual Pulse Duty	20 ~ 80%	
Dual Pulse Base Current Arc Length	-10 ~ +10	
Start Current %	30 ~ 200%	S4T
Start Current Arc Length	-10 ~ +10	
End Current %	30 ~ 200%	
End Current Arc Length	-10 ~ +10	
Hot Start	0 ~ 10	MMA
Arc Force	0 ~ 10	
Two/Four Stroke	2T/4T	TIG
Post Flow	0 ~ 10S	
Down Slope	0 ~ 10S	

Feed Roll Options

Below is listed the range of wire feed rolls available

Model	Feed Roll Pt No	Description	Qty Required
WS-350P	1004V0608	Feed Roll 0.6mm/0.8mm "V" Groove	2
	10054934	Feed Roll 0.8mm/1.0mm "V" Groove	2
	10054932	Feed Roll 1.0mm/1.2mm "V" Groove	2 *
	10054935	Feed Roll 1.2mm/1.6mm "V" Groove	2
	10054930	Feed Roll 1.0mm/1.2mm "U" Groove	2
	10054931	Feed Roll 1.2mm/1.6mm "U" Groove	2
	10062293	Knurled 1.0mm/1.2mm	2
	10062292	Knurled 1.2mm/1.6mm	2
	10054937	Flat Pressure Roll (use with hard wire)	2 *
	10054936	V Pressure Roll 1.00mm/1.2mm (use with soft wire)	2
	10054933	V Pressure Roll 1.2mm/1.6mm (use with soft wire)	2

OPERATION - TIG



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any persons within the welding area.



TIG welding mode

Terms used: TIG – Tungsten Inert Gas, GTAW – Gas Tungsten Arc Welding.

TIG welding is an arc welding process that uses a non-consumable tungsten electrode to produce the heat for welding.

The weld area is protected from atmospheric contamination by a shielding gas (usually an inert gas such as argon or helium) and a filler rod matching the base material is normally used, though some welds, known as autogenous welds, are carried out without the need for filler wire.

Connect the TIG torch power connection (B) to the “-” dinse connector and fully tighten clockwise. Connect the torch trigger plug (C) and the gas connection (D) to the relevant connections on the front panel.



Insert the work return lead cable plug (A) for the work clamp into the “+” dinse socket on the front panel of the welding machine and fully tightened clockwise.

Connect the gas hose to the regulator/flowmeter (E) located on the shield gas cylinder (H) and connect the other end (F) to the machine.

Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any persons within the area.

Now you will need to turn the power switch via the back panel (G) to “ON”

Access the welding mode choice option via the digital display on the user control panel and then select the TIG mode option.

Set the required amperage (along with other TIG parameter functions) via the digital control panel suitable for the application and TIG tungsten being used (see below guide).

Ensure you have adequate welding current according to the thickness of the work and weld prep being carried out and filler wire being used.

Open the gas valve of the cylinder, press the torch trigger and adjust the gas regulator to obtain the desired flow rate.

Once welding is complete release the torch trigger switch which will stop the welding arc but ensure you leave the torch in place to shield the weld with gas for a few seconds until the preset post flow gas turns off.

You also have the option to select either 2T or 4T torch trigger mode via the user interface.

For advanced TIG parameter options please see page 28 for further details.

Tungsten Size	DC – Electrode Negative
1.0mm	15 – 80A
1.6mm	70 – 150A
2.4mm	150 – 250A
3.2mm	250A – 400A

MULTIFUNCTIONAL DISPLAY WINDOW - TIG MODE

Welding screen/display explained WS-M350



Upon powering ON your WS-M350 and boot up is complete, the control panels main menu will appear on the digital panel as shown above. From here the operator can navigate through the various options by rotating the control dial (5) and welding modes which include: Settings, MIG Pulse and Dual Pulse, MIG Synergic, MIG Standard (Manual) and Lift TIG.



When in the home screen, your TIG selection option icon will be shown as the image shows left as Lift TIG, pressing the lower central control dial button (5) will take you into Lift TIG welding mode.



Once Lift TIG welding mode has been selected, you will be taken to the Lift TIG parameter choice display which gives the operator TIG setting options. Rotating the lower central control dial will scroll you through the options of 2T/4T, post flow gas and downslope time and pressing the central control dial will enter the selected parameter to allow you to then adjust said parameter.

Pressing the right control button (6) will save the setting and return you to the parameter screen to allow you to select and adjust other parameter choices.

Pressing the centre dial (5) will save the parameter settings and return you to the 'weld' display as shown in the follow page.

MULTIFUNCTIONAL DISPLAY WINDOW - TIG MODE

Welding screen/display explained WS-M350

Upon selecting and accessing the Lift TIG welding mode you will see the Lift Tig mode welding screen (as shown right).

The left control dial (1) will adjust your preset TIG welding amperage.

The left control dial (1) if pressed for approximately three seconds will access the job 'save' screen where you can select and choose any one of 10 job locations shown as S1 to S10 to save your welding program to.



The right control dial (3) if pressed for approximately three seconds will access the job 'recall' screen where you can select and choose any one of 10 previously saved welding programs shown as R1 to R10

You will note located on the bottom bar shown in the above image TIG parameters of trigger option, post gas and downslope time are shown and their corresponding settings and pressing the right control button (6) will take you into the Lift TIG parameter choice screen where you can adjust the settings (as shown on the previous page) and the Lift TIG parameter setting value ranges are shown below:

Welding parameters	Unit	Welding parameters range
Pre-flow	Seconds	0.0 ~ 2.0
Down Slope	Seconds	0.0 ~ 20
Post-flow	Seconds	0.0 ~ 20

OPERATION - MMA



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any persons within the welding area.

MMA welding mode



MMA (Manual Metal Arc), SMAW (Shielded Metal Arc Welding) or just Stick Welding. Stick welding is an arc welding process which melts and joins metals by heating them with an arc between a covered metal electrode and the work.

Shielding is obtained from the electrode outer coating, often called flux. Filler metal is primarily obtained from the electrode core.

The electrodes outer coating called flux assists in creating the arc and provides a shielding gas and on cooling forms a slag covering to protect the weld from contamination.

When the electrode is moved along the work piece at the correct speed the metal core deposits a uniformed layer called the weld bead.

After connecting the welding leads as detailed you will need to switch the power switch on the back panel to “ON”.



Using the user control display, navigate to the MMA mode, select MMA by switching to the MMA position. There is now open circuit voltage output at both output terminals, (see page 18 for further info on the control panel display function).

Ensure you check that you have the electrode polarity correct (See image left).


Set the amperage on the machine suitable for the electrode being used.

Please see the below a guide to amperages required, although MMA welding electrode guide can vary depending on material, work piece thickness, welding position and joint form.

Electrode Diameter (mm)	Recommended Welding Current (A)
1.6	25 ~ 45
2.0	35 ~ 65
2.5	50 ~ 90
3.2	60 ~ 130
4.0	100 ~ 180
5.0	150 ~ 250
6.0	200 ~ 310

MULTIFUNCTIONAL DISPLAY WINDOW - MMA MODE

Welding screen/display explained WS-M350



Upon powering ON your WS-M350 and boot up is complete, the control panels main menu will appear on the digital panel as shown above. From here the operator can navigate through the various options by rotating the control dial (5) and welding modes which include:

Settings, MIG Pulse and Dual Pulse, MIG Synergic, MIG Standard (Manual) and Lift TIG.

When in the home screen, your MMA selection option icon will be shown as the image shows above as STICK, pressing the lower central control dial button (5) will take you into MMA TIG welding mode.

In the image right you can see how the MMA display appears. The left control dial (1) will adjust your preset welding amperage.

The left control dial (1) if pressed for approximately three seconds will access the job 'save' screen where you can select and choose any one of 10 job locations shown as S1 to S10 to save your welding program to.

The right control dial (3) if pressed for approximately three seconds will access the job 'recall' screen where you can select and choose any one of 10 previously saved welding programs shown as R1 to R10

When in MMA welding mode, pressing the left control 'home' button (4) will take you back to the main welding mode choice screen.

You will note located on the bottom bar MMA parameters of Hot Start and Arc Force are shown and their corresponding settings and pressing the right control button (6) will take you into the MMA parameter choice screen where you can adjust the settings (as shown on the following page).



MULTIFUNCTIONAL DISPLAY WINDOW - MMA MODE

Welding screen/display explained WS-M350


The selection and setting of advanced welding parameters can be carried out in the welding interface screen by pressing the lower right button (6) to enter the welding parameter setting interface.

In this welding parameter setting interface, you will see the available parameters that can be adjusted.

The image right shows the additional parameters for MMA welding of Hot Start current and Arc Force control.

By rotating the control dial (5) you will in-turn select the available parameters as required, select the parameter you wish to adjust, press the control dial (5) to enter that parameter and then will to set a value for the selected parameter.

Pressing the dial again saves your chosen setting and moves to the next parameter.



The MMA parameter setting options and value ranges are shown below:

Welding parameters	Welding parameters range
Hot start	0 ~ 10
Arc force	0 ~ 10

GUIDE TO MIG/MAG WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

MIG process description

The MIG process was first patented for the welding of aluminium in 1949 in the USA.

The process uses the heat that is generated by an electric arc formed between a bare consumable wire electrode and the work piece.

This arc is shielded by a gas to prevent oxidation of the weld.


In the MIG process an inert shielding gas is used to protect the electrode and weld pool from contamination and enhance the arc. Originally this gas was helium.

In the early 1950's the process became popular in the UK for welding aluminium using argon as the shielding gas.

Development in the use of different gases resulted in the MAG process. This is where other gases were used, for example, carbon dioxide and sometimes users refer to the process as CO₂ welding. Gases such as oxygen and carbon dioxide were added and are active constituents to the inert gas to improve the welding performance. Although the MAG process is in common use today it is still referred to as MIG welding although technically this is not correct.

The process began to prove itself as an alternative to stick electrode (MMA) and TIG (GTAW) offering high productivity and deposition rates. The process also helps reduce any weld defects from the increased stop/starts used in MMA. However, the welder must have a good knowledge of the system set up to achieve satisfactory welds.

The electrode MIG gun is normally +VE and the work return is normally -VE. However, certain consumable wires sometimes require what is called reverse polarity i.e. Electrode -VE or work +VE. Typical of these types of wire are cored wires used in hard facing or high deposition and gasless applications.



Typical welding ranges

Wire Diameter (mm)	DIP Transfer		Spray Transfer	
	Current (A)	Voltage (V)	Current (A)	Voltage (V)
0.6	30 ~ 80	15 ~ 18	n/a	n/a
0.8	45 ~ 180	16 ~ 21	150 ~ 250	25 ~ 33
1.0	70 ~ 180	17 ~ 22	230 ~ 300	26 ~ 35
1.2	60 ~ 200	17 ~ 22	250 ~ 400	27 ~ 35
1.6	100 ~ 280	18 ~ 22	250 ~ 500	30 ~ 40

GUIDE TO MIG/MAG WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

Notes for the welding beginner

This section is designed to give the beginner who has not yet done any welding some information to get them going. The simplest way to start is to practice by running weld beads on a piece of scrap plate. Start by using mild steel (paint free) plate of 6.0mm thick and using 0.8mm wire. Clean any grease, oil and loose scale from the plate and fix firmly to your work bench so that welding can be carried out.

Make sure that the work return clamp is secure and making good electrical contact with the mild steel plate, either directly or through the work table. For best results always clamp the work lead directly to the material being welding, otherwise a poor electrical circuit may create itself.

MIG/MAG process features and benefits

Terms used: MIG - Metal Inert Gas Welding,
MAG - Metal Active Gas Welding,
GMAW - Gas Metal Arc Welding

MIG welding was developed to help meet production demands of the war and post war economy which is an arc welding process in which a continuous solid wire electrode is fed through a MIG welding gun and into the weld pool, joining the two base materials together. A shielding gas is also sent through the MIG welding gun and protects the weld pool from contamination which also enhances the arc.

The MIG/MAG process can be used to weld a wide variety of materials and is normally used in the horizontal position but can be used in vertical or overhead with the correct selection of machine, wires and current. In addition, it can be used to weld at long distances from the power source subject to the correct cable sizing.

It is the dominant process used in maintenance and repair industries and is used extensively in structural and fabrication work.

Weld quality is also highly dependent on the skill of the operator and many welding problems can exist due to incorrect installation application and use.

Welding position

When welding, ensure you place yourself in a comfortable position for welding and your welding application before you begin to weld. This maybe sitting at a suitable height which often is the best way to weld ensuring you're relaxed and not tense. A relaxed posture will ensure the welding task becomes much easier.

Please ensure you always wear suitable PPE and use suitable fume extraction when welding.

Place the work so that the direction of welding is across, rather than to or from your body. The electrode holder lead should always be clear of any obstruction so that you can move your arm freely along as the electrode burns down. Some elders prefer to have the welding lead over their shoulder, this allows greater freedom of movement and can reduce the weight from your hand.

Always inspect your welding equipment, welding cables and electrode holder before each use to ensure it's not faulty or worn as you may be at risk of an electric shock.

GUIDE TO MIG/MAG WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

MIG controls

The controls for the MIG/MAG systems are as follows. Controls can be electro mechanical or electronic but the effects will be the same.

Please Note. the below describes standard MIG as Pulse and Synergic can and do function differently.

Wire feed speed

The wire speed is directly related to the current. The higher the wire speed the more wire is deposited and hence more current is required to burn off the consumable wire.

Wire speed is measured in m/min (metres per min) or sometimes in ipm (inches per minute).

The diameter of the wire also forms part of the current demand e.g. a 1.0mm wire feeding at 3m per min will require less current than a 1.2mm wire feeding at the same rate.

The wire feed is set according to the material to be welded.

If the wire feed rate is too high in comparison to the voltage then a “stubbing” effect happens where the un-melted consumable contacts the work piece creating large amounts of weld spatter.

Too little wire feed comparison to the voltage will result in a long arc being created with poor transfer and eventual burning back of the wire onto the contact tip.



Wire Speed

Mode

Voltage

Voltage setting

The voltage polarity in MIG/MAG welding is in the majority of cases with the positive (+). This means that the majority of the heat is in the electrode wire. Certain special wires may require the polarity to be reversed i.e. electrode wire negative (-) polarity. Always consult the manufacturer's data sheet for the best operating parameters.

The voltage is often referred to as the “heat setting”. This will be altered dependent on the material type, thickness, gas type, joint type and position of the weld. Combined with the wire speed it is the main control adjusted by the welder. The voltage setting varies depending on the type and size of electrode wire being used.

Most MIG/MAG welders are CV or Constant Voltage power sources which means the voltage does not vary much during welding. Modern inverter power sources also have control circuits to monitor conditions to ensure voltage remains constant.

The voltage determines height and width of the weld bead. If the operator has no reference to settings required the best method of set up is to use scrap material of the same thickness to obtain the correct setting. If there is too much voltage the arc will be long and uncontrollable and cause the wire to fuse to the contact tip. If the voltage is too low then there will not be enough heat to melt the wire and then stubbing occurs.

To obtain a satisfactory weld a balance needs to be made between voltage and wire speed.

Characteristics of the voltage are that the higher voltage produces a flatter and wider weld bead but care must be taken to avoid undercut. The lower the voltage the weld bead becomes narrow and higher.

GUIDE TO MIG/MAG WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

Burn back control

In the event that the welder was to stop welding and all functions of the machine stopped simultaneously then the consumable filler wire would in all likelihood freeze in the weld pool. In order to avoid this happening the burn back feature is present on this machine.

This facility is usually an adjustable control within these Weld Star compact MIG machines and it will allow the power and gas shield to be maintained on the consumable filler wire when it has stopped feeding thereby burning clear of the weld.

The Weld Star has an in-built burn back facility which is automatically set by the weld parameters selected by the operator.

Some quick reference handy tips for the MIG/MAG welding process are:

- When welding, try to use an electrode stick out (the distance between the weld and the contact tip) of around 6-8mm
- When welding thin materials try and use smaller MIG wire diameters and for thicker materials use thicker wires
- Make sure you select the correct MIG wire type for the material to be welded
- Ensure the MIG welding gun has the correct sized contact tip and type of liner
- Always ensure you have the correct size drive rolls and torch liner for the wire size selected
- Select the correct gas to achieve the correct weld characteristics and finish
- For optimum control of the weld keep the wire at the leading edge of the weld pool
- Before commencing welding, ensure a comfortable and stable position
- Try to keep the welding torch as straight as possible when welding to ensure the best feed
- Carry out daily housekeeping on the condition of the welding torch and drive rolls
- Keep any consumables clean and dry to avoid contamination such as oxidation and damp

MIG SETUP WELDING GUIDE

Please Note: This information is intended to act as a guide only

Low carbon steel, stainless steel pulse MAG welding process reference							
Welding position	Material thickness (MM)	Wire diameter (MM)	Welding current (A)	Welding voltage (V)	Welding speed (CM/MIN)	Nozzle and workpiece spacing (MM)	Gas-flow rate (L/MIN)
Butt Joint	0.8	0.8	60-70	16-16.5	50-60	10-12	10
	1.0	0.8	75-85	17-17.5	50-60	11-13	10-15
	1.2	0.8	80-90	17-18	50-60	12-15	10-15
	1.6	1.0	80-100	19-21	40-50	12-15	10-15
	2.0	1.0	90-100	19-21	40-50	13-16	13-15
	3.2	1.2	150-170	22-25	40-50	14-17	15-17
	4.5	1.2	150-180	24-26	30-40	14-17	15-17
	6.0	1.2	270-300	28-31	60-70	17-22	18-22
	8.0	1.6	300-350	39-34	35-45	20-24	18-22
	10.0	1.6	330-380	30-36	35-45	20-24	18-22
Corner Joint	1.0	0.8	70-80	17-18	50-60	10-12	10-15
	1.2	1.0	85-90	18-19	50-60	11-13	10-15
	1.6	1.0/1.2	100-110	18-19.5	50-60	12-15	10-15
	1.6	1.0	90-130	21-25	40-50	13-16	10-15
	2.0	1.0	100-150	22-26	35-45	13-16	13-15
	3.2	1.2	160-200	23-26	40-50	13-17	13-15
	4.5	1.2	200-240	24-28	45-55	15-20	15-17
	6.0	1.2	270-300	28-31	60-70	18-22	18-22
	8.0	1.6	280-320	27-31	45-60	18-22	18-22
	10.0	1.6	330-380	30-36	40-55	20-24	18-22

MIG SETUP WELDING GUIDE

Please Note: This information is intended to act as a guide only

Welding process of aluminum alloy pulse MIG welding process reference							
Welding position	Material thickness (MM)	Wire diameter (MM)	Welding current (A)	Welding voltage (V)	Welding speed (CM/MIN)	Nozzle and workpiece spacing (MM)	Gas-flow rate (L/MIN)
Butt Joint	1.5	1.0	60-80	16-18	60-80	12-15	15-20
	2.0	1.0	70-80	17-18	40-50	15	15-20
	3.0	1.2	80-100	17-20	40-50	14-17	15-20
	4.0	1.2	90-120	18-21	40-50	14-17	15-20
	6.0	1.2	150-180	20-23	40-50	17-22	18-22
	4.0	1.2	160-210	22-25	60-90	15-20	19-20
	4.0	1.6	170-200	20-21	60-90	15-20	19-20
	6.0	1.2	200-230	24-27	40-50	17-22	20-24
	6.0	1.6	200-240	21-23	40-50	17-22	20-24
	8.0	1.6	240-270	24-27	45-55	17-22	20-24
	12.0	1.6	270-330	27-35	55-60	17-22	20-24
	16.0	1.6	330-400	27-35	55-60	17-22	20-24
Corner Joint	1.5	1.0	60-80	16-18	60-80	13-16	15-20
	2.0	1.0	100-150	22-26	35-45	13-16	15-20
	3.0	1.2	100-120	19-21	40-60	13-17	15-20
	4.0	1.2	120-150	20-22	50-70	15-20	15-20
	6.0	1.2	150-180	20-23	50-70	18-22	18-22
	4.0	1.2	180-210	21-24	35-50	18-22	16-18
	4.0	1.6	180-210	18-20	35-45	18-22	18-22
	6.0	1.2	220-250	24-25	50-60	18-22	16-24
	6.0	1.6	220-240	20-24	37-50	18-22	16-24
	8.0	1.6	250-300	25-26	60-65	18-22	16-24
	12.0	1.6	300-400	26-28	65-75	18-22	16-24

MIG WELDING PROBLEMS



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

MIG welding defects and prevention methods

<u>Defect</u>	<u>Possible cause</u>	<u>Action</u>
Porosity (within or outside the bead)	Poor material	Check the material is clean
	Insufficient shield gas flow	Check hoses and MIG torch for blockages
	Gas flow too low/high	Check the regulator setting or that it is not frozen due to a high flow
	Leaking hoses	Check all hoses for leaks
	Faulty gas valve	Call a service engineer
	Working in open area with drafts	Put screens up around the weld area
Poor or inconsistent wire feed	Incorrect pressure on wire drive causing burn back to contact tip or bird nesting at the feed roll	Readjust the upper feed pressure
		Increase the pressure to eliminate burn back to tip
		Decrease pressure to eliminate bird nesting
	Damage to torch liner	Replace torch liner
	Welding wire contaminated or rusty	Replace wire
	Worn welding tip	Check and replace welding tip
No operation when the torch switch is operated	Torch switch faulty	Check the torch switch continuity and replace if faulty
	Fuse blown	Check fuses and replace if necessary
	Faulty PCB inside the equipment	Call a service engineer
Low output current	Loose or defective work clamp	Tighten/replace clamp
	Loose cable plug	Re-fix plug
	Power source faulty	Call a service engineer
No operation	No operation and mains lamp not lit	Check mains fuse and replace if required
	Faulty power source	Call a service engineer
Excessive spatter	Wire feed speed too high or welding voltage too low	Reset the parameters according to the weld to be made
Excessive penetration, the weld metal is below the surface level of the material and hangs below	Heat input too high	Reduce the amperage or use a smaller electrode and lower amperage
	Poor weld technique	Use correct welding travel speed

MIG WELDING PROBLEMS



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

MIG welding defects and prevention methods

<u>Defect</u>	<u>Possible cause</u>	<u>Action</u>
Burning through – Holes within the material where no weld exists	Heat input too high	Use lower amperage or smaller electrode Use correct welding travel speed
Poor fusion – Failing of weld material to fuse either with the material to be welded or previous weld beads	Insufficient heat level Poor welding technique Work piece dirty	Increase the amperage or increase the electrode size and amperage Joint design must allow for full access to the root of the weld Alter welding technique to ensure penetration such as weaving, arc positioning or stringer bead technique Remove all contaminant from the material i.e. oil, grease, rust, moisture prior to welding
Irregular weld bead and shape	Incorrect voltage/wire feed settings. If its convex then the voltage is too low and if its concave then the voltage is too high. Insufficient or excessive heat input Wire is wandering Incorrect shielding gas	Adjust voltage and/or wire feed speed Adjust the wire feed speed dial or the voltage control Replace contact tip Check and change the shielding gas as required
Your weld is cracking	The weld beads too small Weld penetration narrow and deep Excessive voltage Weld/material cooling rate too fast	Try decreasing the travel speed Try reducing the wire feed speed current and voltage or increase MIG torch travel speed Decrease voltage control dial Slow the cooling rate by preheating part to be welded or cool slowly
The welding arc does not have a crisp sound that short arc exhibits when the wire feed speed or voltage are adjusted correctly	The MIG torch may have been connected to the wrong output voltage polarity on the front panel	Ensure that the MIG torch polarity lead is connected to the positive (+) welding terminal for solid wires and gas shielded flux cored wires

MIG TORCH SPARE PARTS LIST

Weld Star WS-M350 Air Cooled


MIG Welding Torch Air Cooled - Model: T360

T360 Rating 340A Co2 / 300A Mixed Gases @ 60% Duty Cycle EN60974-7 Wire Size 0.8mm to 1.6mm



Torch Packages

T360-3	T360-4	T360-5
3 metre	4 metre	5 metre
*Euro Fitting and Bladeswitch		



Main Consumables

	Code	Description	Pack Qty
1	SP3654	Swan Neck Complete	1
2	SP3658	Diffuser Black	5
	SP3658W	Diffuser White	5
	SP3658C	Diffuser Ceramic	5
3	SP3681	Tip Adaptor Short M6 Tips	5
	SP3683 *	Tip Adaptor Short M8 Tips	5
	SP3682	Tip Adaptor Long M6 Tips	5
	SP3684 *	Tip Adaptor Long M8 Tips	5
4	SP3670	Nozzle Conical	5
	SP3671	Nozzle Cylindrical	5
	SP3672	Nozzle Tapered	5
	SP3673	Nozzle Bottle	5
	SP3674	Spot Welding Nozzle	5

Contact Tips (ECU M6 x 28mm)

5	SP2408	0.8mm Steel / 0.6mm Alum Wire	25
	SP2409	0.9mm Steel Wire	25
	SP2410	1.0mm Steel / 0.8mm Alum Wire	25
	SP2412	1.2mm Steel / 1.0mm Alum Wire	25
	SP2414	1.4mm Steel / 1.2mm Alum Wire	25
	SP2416	1.6mm Steel Wire	25

* For specifically marked ALU Tips add 'A' after the part number eg: SP2410A

Contact Tips (CuCrZr M6 x 28mm)

	SP2508	0.8mm Steel / 0.6mm Alum Wire	25
	SP2509	0.9mm Steel Wire	25
	SP2510	1.0mm Steel / 0.8mm Alum Wire	25
	SP2512	1.2mm Steel / 1.0mm Alum Wire	25
	SP2516	1.6mm Steel Wire	25

Liners (Steel Plastic Coated)

	Code	Description	Pack Qty
6	SP1539	0.6 - 0.9mm x 3m - PC Blue	1
	SP1549	0.6 - 0.9mm x 4m - PC Blue	1
	SP1559	0.6 - 0.9mm x 5m - PC Blue	1
	SP2432	1.0 - 1.2mm x 3m - PC Red	1
	SP2442	1.0 - 1.2mm x 4m - PC Red	1
	SP2452	1.0 - 1.2mm x 5m - PC Red	1
	SP2436	1.6mm x 3m - PC Yellow	1
	SP2446	1.6mm x 4m - PC Yellow	1
	SP2456	1.6mm x 5m - PC Yellow	1

Liners (PTFE)

	SP1538T	0.6 - 0.8mm x 3m - Blue	1
	SP1548T	0.6 - 0.8mm x 4m - Blue	1
	SP1558T	0.6 - 0.8mm x 5m - Blue	1
	SP2432T	1.0 - 1.2mm x 3m - Red	1
	SP2442T	1.0 - 1.2mm x 4m - Red	1
	SP2452T	1.0 - 1.2mm x 5m - Red	1
	SP2436T	1.6mm x 3m - Yellow	1
	SP2446T	1.6mm x 4m - Yellow	1
	SP2456T	1.6mm x 5m - Yellow	1
	SP1511	Liner Collet 0.6-1.2mm	5
	SP1511-47	Liner Collet 1.6mm	5
	SP1517	Liner 'O' Ring	10

Secondary Consumables

7	SP1625	Complete Bladeswitch Handle c/w Cable Support	1
8	SP3603	Cable Assy 3m	1
	SP3604	Cable Assy 4m	1
	SP3605	Cable Assy 5m	1
9	SP8003	Complete Euro Connection Kit c/w Support	1
10	SP1596	Gun Plug 'O' Ring	10
11	SP1597	Liner Retaining Nut	5

* For 8mm Threaded Tips Use SP38 / SP40 Series See Page 194 Item No. 6

MIG TORCH SPARE PARTS LIST

Weld Star WS-M350 Water Cooled

MIG Welding Torch Water Cooled - Model: T501


Rating 500A Co2 / 450A Mixed Gases @ 100% Duty Cycle EN60974-7 Wire Size 1.0mm to 1.6mm



Torch Packages

T501-3	T501-4	T501-5
3 metre	4 metre	5 metre

*Euro Fitting and Bladeswitch



Main Consumables

Code	Description	Pack Qty
1	SP5054 Swan Neck	1
2	SP4055 Insulating Washer	10
3	SP3858 Diffuser Black	5
	SP3858W Diffuser White	5
	SP3858C Diffuser Ceramic	5
4	SP4081 Tip Adaptor Short M8 Tips	5
	SP4082* Tip Adaptor M6 Tips	5
	SP4083 Tip Adaptor Long M8 Tips	5
5	SP2670 Nozzle Conical	5
	SP2671 Nozzle Cylindrical	5
	SP2672 Nozzle Tapered	5

Contact Tips (ECU M8 x 30mm)

6	SP3810 1.0mm Steel / 0.8mm Alum Wire	25
	SP3812 1.2mm Steel / 1.0mm Alum Wire	25
	SP3814 1.4mm Alum / 1.2mm Alum Wire	25
	SP3816 1.6mm Steel Wire	25

* For specifically marked ALU Tips add 'W' after the part number
eg: SP3810A

Contact Tips (CuCrZr M8 x 30mm)

	SP4008 0.8mm Steel / 0.6mm Alum Wire	25
	SP4010 1.0mm Steel / 0.8mm Alum Wire	25
	SP4012 1.2mm Steel / 1.0mm Alum Wire	25
	SP4014 1.4mm Alum Wire	25
	SP4016 1.6mm Steel Wire	25

Liners (Steel)

Code	Description	Pack Qty
7	SP3531 0.8 - 1.0mm x 3m	1
	SP3541 0.8 - 1.0mm x 4m	1
	SP3551 0.8 - 1.0mm x 5m	1
	SP3532 1.0mm-1.2mm x 3m	1
	SP3542 1.0mm-1.2mm x 4m	1
	SP3552 1.0mm-1.2mm x 5m	1
	SP3536 1.6mm x 3m	1
	SP3546 1.6mm x 4m	1
	SP3556 1.6mm x 5m	1

Liners (PTFE)

	SP2432T 1.0 - 1.2mm x 3m	1
	SP2442T 1.0 - 1.2mm x 4m	1
	SP2452T 1.0 - 1.2mm x 5m	1
	SP2436T 1.6mm x 3m	1
	SP2446T 1.6mm x 4m	1
	SP2456T 1.6mm x 5m	1
	SP1511 Liner Collet 0.6mm-1.2mm	5
	SP1511-47 Liner Collet 1.6mm	5
	SP1517 Liner 'O' Ring	10

Secondary Consumables

Code	Description	Pack Qty
8	SP1626 Bladeswitch Handle c/w Cable Support	1
9	SP3503 Complete Cable Assy 3m	1
	SP3504 Complete Cable Assy 4m	1
	SP3505 Complete Cable Assy 5m	1
	SP3535 Power Cable Assy 3m	1
	SP3545 Power Cable Assy 4m	1
	SP3555 Power Cable Assy 5m	1
	SP3537 Outer Liner Assy 3m	1
	SP3547 Outer Liner Assy 4m	1
	SP3557 Outer Liner Assy 5m	1
	SP3530 Gas Hose 3m	1
	SP3540 Gas Hose 4m	1
	SP3550 Gas Hose 5m	1
	SP3533 Trigger Cable Per m	1
	SP3513 Canvas Cover Per m	1
10	SP3523 Water Inlet Hose Per m	1
11	SP3515 Water Outlet Hose 0.5m	1
12	SP3526 Hose Nipple	10
13	SP8004 Euro Connector Kit c/w Cable Support	1
14	SP1596 Gun Plug 'O' Ring	10
15	SP1597 Liner Retaining Nut	5

* For 6mm Threaded Tips Use SP24 / SP25 Series
See Page 192 Item No. 5

GUIDE TO DC TIG WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

DC welding


Direct current welding is when the current flows in one direction only. Compared with AC welding the current once flowing will not go to zero until welding has ended.

The Weld Star TIG Series polarity should generally be set up for Direct Current - Electrode Negative (DCEN) as this method of welding can be used for a wide range of materials.

The TIG welding torch is connected to the negative output of the machine and the work return cable to the positive output.

When the arc is established the current flows in the circuit and the heat distribution in the arc is around 33% in the negative side of the arc (the welding torch) and 67% in the positive side of the arc (the work piece). This balance gives deep arc penetration of the arc into the work piece and reduces heat in the electrode.

This reduced heat in the electrode allows more current to be carried by smaller electrodes compared to other polarity connections. This method of connection is often referred to as straight polarity and is the most common connection used in DC welding.



TIG welding techniques

- Before welding (especially with mild steel) you should ensure all material being welded are clean, as particulates can weaken the weld
- The torch angle is best kept at 15 - 20° (from vertical) away from the direction of travel. This assists with visibility of the weld area and allows easier access for the filler material
- The filler metal should be fed in at a low angle to help avoid touching the tungsten electrode and contaminating it
- The TIG welding arc melts the base material and the molten puddle melts the filler rod, it is important you resist the urge to melt the filler material directly into the welding arc
- For thinner sheet materials, a filler material may not be needed
- Prepare the tungsten correctly, using a diamond grinding wheel will give you the best results for a sharp point see page 36
- For welding stainless steel, be careful of applying too much heat. If the colour is dark grey and looks dirty and heavily oxidized then too much heat has been applied, this could also cause the material to warp. Reducing the amperage and increase travel speed may correct this problem, you could also consider using a smaller diameter filler material, as that will require less energy to melt

Please see the following page for the TIG DC welding amperage guide.

GUIDE TO DC TIG WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

Manual DC TIG Welding Amperage Guide- Mild Steel and Stainless Steel

Base Metal Thickness mm	Base Metal Thickness Inch	Tungsten Electrode Diameter	Output Polarity	Filler Wire Diameter (If Required)	Argon Gas Flow Rate (Litres/Min)	Joint Types	Amperage Range
1.6mm	1/16"	1.6mm	DC	1.6mm	5 - 8	Butt	50 - 80
1.6mm	1/16"	1.6mm	DC	1.6mm	5 - 8	Corner	50 - 80
1.6mm	1/16"	1.6mm	DC	1.6mm	5 - 8	Fillet	60 - 90
1.6mm	1/16"	1.6mm	DC	1.6mm	5 - 8	Lap	60 - 90
2.4mm	3/32"	1.6/2.4mm	DC	1.6/2.4mm	5 - 9	Butt	80 - 110
2.4mm	3/32"	1.6/2.4mm	DC	1.6/2.4mm	5 - 9	Corner	80 - 110
2.4mm	3/32"	1.6/2.4mm	DC	1.6/2.4mm	5 - 9	Fillet	90 - 120
2.4mm	3/32"	1.6/2.4mm	DC	1.6/2.4mm	5 - 9	Lap	90 - 120
3.2mm	1/8"	2.4mm	DC	2.4mm	5 - 10	Butt	80 - 120
3.2mm	1/8"	2.4mm	DC	2.4mm	5 - 10	Corner	90 - 120
3.2mm	1/8"	2.4mm	DC	2.4mm	5 - 10	Fillet	100 - 140
3.2mm	1/8"	2.4mm	DC	2.4mm	5 - 10	Lap	100 - 140
4.8mm	3/16"	2.4mm	DC	2.4mm	6 - 11	Butt	120 - 200
4.8mm	3/16"	2.4mm	DC	2.4mm	6 - 11	Corner	150 - 200
4.8mm	3/16"	2.4mm	DC	2.4mm	6 - 11	Fillet	170 - 220
4.8mm	3/16"	2.4mm	DC	2.4mm	6 - 11	Lap	150 - 200
6.4mm	1/4"	2.4mm	DC	3.2mm	7 - 12	Butt	225 - 300
6.4mm	1/4"	2.4mm	DC	3.2mm	7 - 12	Corner	250 - 300
6.4mm	1/4"	2.4mm	DC	3.2mm	7 - 12	Fillet	250 - 320
6.4mm	1/4"	2.4mm	DC	3.2mm	7 - 12	Lap	250 - 320
9.5mm	3/8"	3.2mm	DC	3.2mm	7 - 12	Butt	250 - 360
9.5mm	3/8"	3.2mm	DC	3.2mm	7 - 12	Corner	260 - 360
9.5mm	3/8"	3.2mm	DC	3.2mm	7 - 12	Fillet	270 - 380
9.5mm	3/8"	3.2mm	DC	3.2mm	7 - 12	Lap	230 - 380
12.7mm	1/2"	3.2/4mm	DC	3.2mm	8 - 13	Butt	300 - 400
12.7mm	1/2"	3.2/4mm	DC	3.2mm	8 - 13	Corner	320 - 420
12.7mm	1/2"	3.2/4mm	DC	3.2mm	8 - 13	Fillet	320—420
12.7mm	1/2"	3.2/4mm	DC	3.2mm	8 - 13	Lap	320 - 420

Please Note:

- All above guide settings are approximate and will vary depending on application, prep, passes and type of welding equipment used.
- The welds would need to be tested to ensure they comply to your welding specifications.


GUIDE TO TIG WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

TIG torch body and components

The torch body holds the various welding consumables in place as shown and is covered by a either a rigid phenolic or rubberised covering.



Collet body



The collet body screws into the torch body. It is replaceable and is changed to accommodate the different size tungsten's and their respective collets.

Collets



The welding electrode (tungsten) is held in the torch by the collet. The collet is usually made of copper or a copper alloy. The collet's grip on the electrode is secured when the torch back cap is tightened in place. Good electrical contact between the collet and tungsten electrode is essential for good welding current transfer.

Gas lens body



A gas lens is a device that can be used in place of the normal collet body. It screws into the torch body and is used to reduce turbulence in the flow of shield gas and produce a stiff column of undisturbed flow of shielding gas. A gas lens will allow the welder to move the nozzle further away from the joint allowing increased visibility of the arc.

A much larger diameter nozzle can be used which will produce a large blanket of shielding gas. This can be very useful in welding material like titanium. The gas lens will also enable the welder to reach joints with limited access such as inside corners.

Ceramic cups



Gas cups are made of various types of heat resistant materials in different shapes, diameters and lengths. The cups are either screwed onto the collet body or gas lens body or in some cases pushed in place. Cups can be made of ceramic, metal, metal-jacketed ceramic, glass or other materials. The ceramic type is quite easily broken so take care when putting the torch down.

Gas cups must be large enough to provide adequate shielding gas coverage to the weld pool and surrounding area. A cup of a given size will allow only a given amount of gas to flow before the gas flow becomes disturbed due to the speed of flow. Should this condition exist the size of cup should be increased to allow the flow speed to reduce and once again establish an effective regular shield.

Back cap

The back cap screws into the rear on the torch head and applies pressure to the back end of the collet which in turn forces up against the collet body, the resulting pressure holds the tungsten in place to ensure it does not move during the welding process.

Back caps are made from a rigid phenolic material and generally come in 3 sizes, short, medium and long.

GUIDE TO TIG WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

TIG welding electrodes

TIG welding electrodes are a 'non consumable' as it is not melted into the weld pool and great care should be taken not to let the electrode contact the welding pool to avoid weld contamination. This would be referred to as tungsten inclusion and may result in weld failure.

Electrodes will often contain small quantities of metallic oxides which can offer the following benefits:

- Assist in arc starting
- Improve current carrying capacity of the electrode
- Reduce the risk of weld contamination
- Increase electrode life
- Increase arc stability

Oxides used are primarily zirconium, thorium, lanthanum or cerium. These are added usually 1% - 4%.



Tungsten Electrode Colour Chart - DC


Welding Mode	Tungsten Type	Colour
DC or AC/DC	Ceriated 2%	Grey
DC or AC/DC	Lanthanated 1%	Black
DC or AC/DC	Lanthanated 1.5%	Gold
DC or AC/DC	Lanthanated 2%	Blue
DC	Thoriated 1%	Yellow
DC	Thoriated 2%	Red

Tungsten Electrode Current Ranges

Tungsten Electrode Size	DC Current Amp
1.0mm	30 - 60
1.6mm	60 - 115
2.4mm	100 - 165
3.2mm	135 - 200
4.0mm	190 - 280
4.8mm	250 - 340


Tungsten electrode preparation - DC

When welding at low current the electrode can be ground to a point. At higher current a small flat on the end of the electrode is preferable as this helps with arc stability.



Electrode grinding

It is important when grinding the electrode to take all necessary precautions such as wearing eye protection and ensuring adequate protection against breathing in any grinding dust.



Tungsten electrodes should always be ground lengthwise (as shown) and not in a radial operation. Electrodes ground in a radial operation tend to contribute to arc wander due to the arc transfer from the grinding pattern. Always use a grinder solely for grinding electrodes to avoid contamination.

GUIDE TO TIG WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

TIG welding consumables

The consumables of the TIG welding process are filler wires and shield gas.

Filler wires

Filler wires come in many different material types and usually as cut lengths, unless some automated feeding is required where it will be in reel form.

Filler wire is generally fed in by hand.

Always consult the manufacturer's data and welding requirements.

Filler Wire Diameter	DC Current Range (Amps)
1.0mm	20-90
2.4mm	65-115
3.2mm	100-165
4.8mm	200-350

Filler Wire Selection Guide

Gases


Shielding gas is required when welding to keep the weld pool free of oxygen. Whether you are welding mild steel or stainless steel the most commonly used shielding gas used in TIG welding is argon, for more specialised applications an argon helium mix or pure helium maybe used.

TIG welding arc starting - Lift TIG (lift arc)

Not to be confused with scratch start, this arc starting method allows the tungsten to be in direct contact with the work piece first but with minimal current so as not to leave a tungsten deposit when the tungsten is lifted and an arc is established.

With lift TIG start the open circuit voltage (OCV) of the welder folds back to a very low voltage output when the unit senses it has made continuity with the work piece. Once the torch is lifted the unit increases output as the tungsten leaves the surface. This creates little contamination and preserves the point on the tungsten although this is still not a 100% clean process.

The tungsten can still get contaminated but lift TIG is still a much better option than scratch starting for mild and stainless steel although these methods of arc starting are not a good option when welding aluminium.



GUIDE TO TIG WELDING




Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

Arc starting - lift TIG (lift arc)

Not to be confused with scratch start, this arc starting method allows the tungsten to be in direct contact with the work piece first but with minimal current so as not to leave a tungsten deposit when the tungsten is lifted and an arc is established.

With lift TIG start the open circuit voltage (OCV) of the welder folds back to a very low voltage output when the unit senses the tungsten has made continuity with the work piece. Once the torch is lifted the unit increases output as the tungsten leaves the surface. This creates little contamination and preserves the point on the tungsten although this is still not a 100% clean process. The tungsten still can get contaminated but lift TIG is a much better option than scratch starting for mild and stainless steel although these methods of arc starting are not a good option when welding aluminium.



Arc starting - HF start

Non contact High Frequency (HF) start method is a high voltage and low amperage generated using a spark gap assembly and is the most popular and generally considered best TIG arc starting method. The High Frequency (HF) start generates a high frequency arc that ionizes the gas bridging the gap between the tungsten point and the work piece. This touchless method creates almost no contamination unless the tungsten has been over sharpened or the start amperage is too high. It is an excellent choice for all material being welded especially aluminium although, unless you need to weld aluminium, you don't have to use HF start steel/stainless.

The HF frequency varies with the spark gap and can be around 16000 Hz to 100000 Hz depending on spark gap width so consideration should be given with this method as it can cause electrical interference to nearby electrical equipment such as computers, CNC controls and phone systems.

If the spark gap is widened, the HF can become erratic.



TIG WELDING PROBLEMS



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

TIG welding defects and prevention methods

Defect	Possible cause	Action
Excessive tungsten use	Set up for DCEP	Change to DCEN
	Insufficient shield gas flow	Check for gas restriction and correct flow rates. Check for drafts in the weld area.
	Electrode size too small	Select correct size
	Electrode contamination during cooling time	Extend post flow gas time
Porosity/weld contamination	Loose torch or hose fitting	Check and tighten all fittings
	Inadequate shield gas flow	Adjust flow rate - normally 8-12L/m
	Incorrect shield gas	Use correct shield gas
	Gas hose damaged	Check and repair any damaged hoses
	Base material contaminated	Clean material properly
	Incorrect filler material	Check correct filler wire for grade of use
No operation when torch switch is operated	Torch switch or cable faulty	Check the torch switch continuity and repair or replace as required
	ON/OFF switch turned off	Check position of ON/OFF switch
	Mains fuses blown	Check fuses and replace as required
	Fault inside the machine	Call for a repair technician
Low output current	Loose or defective work clamp	Tighten/replace clamp
	Loose cable plug	Check and tighten all plugs
	Power source faulty	Call a repair technician
Will not strike an arc	Weld/power cable open circuit	Check all cables and connections for continuity, especially the torch cables
	No shield gas flowing	Check cylinder contents, regulator and valves, also check the power source
Unstable arc when welding in DC	Tungsten contaminated	Break off contaminated end and regrind the tungsten
	Arc length incorrect	Arc length should be between 3-6mm
	Material contaminated	Clean all base and filler material
	Electrode connected to the wrong polarity	Reconnect to correct polarity
Arc is difficult to start	Incorrect tungsten type	Check and fit correct tungsten
	Incorrect shield gas	Use argon shield gas

TIG WELDING PROBLEMS



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

TIG welding defects and prevention methods

<u>Defect</u>	<u>Possible cause</u>	<u>Action</u>
Excessive bead build up, poor penetration or poor fusion at the edges of the weld	Weld current too low	Increase the welding amperage Poor material prep
Weld bead flat and too wide or undercut at the weld edge or burning through	Weld current too high	Decrease the welding amperage
Weld bead too small or insufficient penetration	Welding travel speed too fast	Reduce your welding travel speed
Weld bead too wide or excessive bead build up	Welding travel speed too slow	Increase your welding travel speed
Uneven leg length in fillet joint	Wrong placement of filler rod	Re-position filler rod
Tungsten melts or oxidises when welding arc is made	TIG torch lead connected to + Little or no gas flow to weld pool	Connect to - polarity Check gas apparatus as well as torch and hoses for breaks or restrictions
	Gas cylinder or hoses contain impurities The tungsten is too small for the weld current TIG/MMA selector set to MMA	Change gas cylinder and blow out torch and gas hoses Increase the size of the tungsten Ensure you have the power source set to TIG function

GUIDE TO MMA WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

Notes for the welding beginner

This section is designed to give the beginner who has not yet done any welding some information to get them going. The simplest way to start is to practice by running weld beads on a piece of scrap plate. Start by using mild steel (paint free) plate of 6.0mm thick and using 3.2mm electrodes. Clean any grease, oil and loose scale from the plate and fix firmly to your work bench so that welding can be carried out. Make sure that the work return clamp is secure and making good electrical contact with the mild steel plate, either directly or through the work table. For best results always clamp the work lead directly to the material being welded, otherwise a poor electrical circuit may create itself.

Welding position

When welding, ensure you place yourself in a comfortable position for welding and your welding application before you begin to weld. This maybe sitting at a suitable height which often is the best way to weld ensuring you're relaxed and not tense. A relaxed posture will ensure the welding task becomes much easier.

Please ensure you always wear suitable PPE and use suitable fume extraction when welding.

Place the work so that the direction of welding is across, rather than to or from your body. The electrode holder lead should always be clear of any obstruction so that you can move your arm freely along as the electrode burns down. Some elders prefer to have the welding lead over their shoulder, this allows greater freedom of movement and can reduce the weight from your hand.

Always inspect your welding equipment, welding cables and electrode holder before each use to ensure it's not faulty or worn as you may be at risk of an electric shock.

MMA process features and benefits

The versatility of the process and the skill level required to learn, basic simplicity of the equipment make the MMA process one of the most common used throughout the world.

The MMA process can be used to weld a wide variety of materials and is normally used in the horizontal position but can be used in vertical or overhead with the correct selection of electrode and current. In addition, it can be used to weld at long distances from the power source subject to the correct cable sizing. The self shielding effect of the electrode coating makes the process suitable for welding in external environments. It is the dominant process used in maintenance and repair industries and is used extensively in structural and fabrication work.

The process is well able to cope with less than ideal material conditions such as dirty or rusty material. Disadvantages of the process are the short welds, slag removal and stop/starts which lead to poor weld efficiency which is in the region of 25%. The weld quality is also highly dependent on the skill of the operator and many welding problems can exist.

GUIDE TO MMA WELDING




Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

MMA process tips and guides

Typical welder set up

1. Electrode holder
2. Work return clamp
3. Work piece
4. Weld material covered by electrode flux or slag
5. Electrode
6. Distance from work to electrode (arc Length)




Welding current will flow in the circuit as soon as the electrode contacts the work piece. The welder should always ensure a good connection of the work clamp. The nearer the clamp is placed to the welding area the better.

When the arc is struck the distance between the end of the electrode and the work will determine the arc voltage and also affect the weld characteristic. As a guide the arc length for electrodes up to 3.2mm diameter should be around 1.6mm and over 3.2mm around 3mm.

Upon completion of the weld the welding flux or slag will need to be removed usually with a chipping hammer and wire brush.

Joint form in MMA

In MMA welding, the common basic joint forms: butt joint, corner joint, lap joint & T joint.




GUIDE TO MMA WELDING




Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

MMA arc striking

Tap technique - Lift the electrode upright and bring it down to strike the work piece. After forming short circuit, quickly lift up about 2~4mm and arc will be ignited. This method is difficult to master.




Scratch technique - Drag the electrode and scratch the work piece as if striking a match. Scratching the electrode may cause the arc to burn along the scratch path, so care should be taken to scratch in the weld zone. When the arc is struck adopt the correct welding position.



Electrode positioning

Horizontal or flat position

The electrode should be positioned at right angles to the plate and inclined in the direction of travel at around 10°-30°.




GUIDE TO MMA WELDING



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

Fillet welding


The electrode should be positioned to split the angle i.e. 45° . Again the electrode should be inclined in the direction of travel at around 10° - 30° .



Manipulation of electrode

In MMA welding there are three motions used at the end of electrode:

1. The electrode feeding to the molten pool along axes
2. The electrode swing right and left
3. The electrode moving in the weld direction



The operator can choose the manipulation of electrode based on welding joint, welding position, electrode spec, welding current and operation skill etc.

Weld characteristics

A good weld bead should exhibit the following characteristics:

1. Uniform weld bead
2. Good penetration into the base material
3. No overlap
4. Fine spatter level

A poor weld bead should exhibit the following characteristics:

1. Uneven and erratic bead
2. Poor penetration into the base material
3. Bad overlap
4. Excessive spatter levels
5. Weld crater

MMA WELDING PROBLEMS



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

Arc welding defects and prevention methods

<u>Defect</u>	<u>Possible cause</u>	<u>Action</u>
Excessive spatter (beads of metal scattered around the weld area)	Amperage too high for the selected electrode	Reduce amperage or utilise larger diameter electrode
	Voltage too high or arc length too long	Reduce arc length or voltage
Uneven and erratic weld bead and direction	Weld bead is inconsistent and misses joint due to operator	Operator training required
Lack of penetration – The weld bead fails to create complete fusion between material to be welded, often surface appears okay but weld depth is shallow	Poor joint preparation	Joint design must allow for full access to the root of the weld
	Insufficient heat input	Material too thick Increase the amperage or increase the electrode size and amps
	Poor weld technique	Reduce travel speed Ensure the arc is on the leading edge of the weld puddle
Porosity – Small holes or cavities on the surface or within the weld material	Work piece dirty	Remove all contaminant from the material i.e. oil, grease, rust, moisture prior to welding
	Electrode is damp	Replace or dry the electrode
	Arc length is excessive	Reduce the arc length
Excessive penetration – The weld metal is below the surface level of the material and hangs below	Heat input too high	Reduce the amperage or use a smaller electrode and lower amperage
	Poor weld technique	Use correct welding travel speed
Burning through – Holes within the material where no weld exists	Heat input too high	Use lower amperage or smaller electrode Use correct welding travel speed
Poor fusion – Failing of weld material to fuse either with the material to be welded or previous weld beads	Insufficient heat level	Increase the amperage or increase the electrode size and amperage
	Poor welding technique	Joint design must allow for full access to the root of the weld Alter welding technique to ensure penetration such as weaving, arc positioning or stringer bead technique
	Work piece dirty	Remove all contaminant from the material i.e. oil, grease, rust, moisture prior to welding

REMOTE CONTROL SOCKET



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.


Remote control socket

The 9 pin remote control socket located on the front panel is used to connect a TIG torch trigger with switch and/or torch mounted 'analogue' current adjustment dial, a foot pedal for TIG welding. See following page for spool gun option.

Remote socket pin and wiring configuration

The Weld Star TIG welding machine can accept a remote current control signal from an analogue type potentiometer arrangement source as shown to the right.

Potentiometer remote control will change the current from 5amp to maximum set using the machine current control.



TIG torch with remote amperage control via a potentiometer

Connect the TIG torch control plug to the machines 9 pin remote socket and place the machine torch trigger mode into 4T (see from page 24).

Press the TIG torch switch to start the machine output functions. The finger controlled torch handle mounted current potentiometer controls the welding amperage (by rotating clockwise/anti clockwise) up to the already pre-set level set on the welding power source control panel. With a TIG torch current control connected, the machines digital ammeter will display the pre-set preview amps until the torch switch is pressed, when welding commences it will then display actual welding current depending on where your torch mounted potentiometer is positioned.



Foot pedal amperage control

Connect the foot pedal control plug to the machines 9 pin remote socket and place the torch trigger mode into 2T (see page 24). Press the foot pedal down to start the machine output functions.

The foot control potentiometer controls the welding current up to the preset level set on the welding power source control panel. With the foot control connected, the panel digital ammeter will display the pre-set preview amps until the foot control is depressed then it displays actual welding current when welding.

Please note:

The maximum output current must be set on the power source control panel by the user prior to the foot control being connected.

SPOOL GUN OPERATION



Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any personnel within the welding area.

Spool Gun Welding Mode

The Weld Star WS-M350 can be used with our optional spool gun which is a Euro style spool gun that connects to the M350 via the Euro outlet connector.

Connect the spool gun Euro plug to the (MIG) euro socket. Connect the spool gun 9 pin control plug to its matching 9 pin socket located on the front panel of the machine.

Ensure the trailing lead is connected into the “+” socket on the front panel of the machine and tighten clockwise.

Insert the cable plug for the work clamp into the “-” socket on the front panel of the welding machine and tighten clockwise.

Connect the gas hose to the regulator/flowmeter located on the shield gas cylinder and connect the other end to the machine.

Before starting any welding activity ensure that you have suitable eye protection and protective clothing. Also take the necessary steps to protect any persons within the area.

After connecting the welding leads as detailed above you will need to switch the power switch on the back panel to “ON” and select MIG Spool Gun welding mode, you can use the spool gun in standard, pulse or synergic MIG modes.

Set the welding voltage and other parameters via the machine user interface although wire feed speed is adjusted from the wire feed control potentiometer fitted on the spool gun.

Ensure you have adequate welding current according to the thickness of the work and weld prep being carried out.

Fit your 1Kg reel of welding wire to the spool holder and feed the wire through the drive rolls ensuring the fitted roller sizes matches your wire type and size, then continue to feed the wire through the contact tip again ensuring you have the correct size tip fitted.

Open the gas valve of the cylinder, press the torch trigger and adjust the gas regulator to obtain the desired flow rate.

Adjust the “voltage” control knob on the front panel of the machine to set the correct welding voltage and adjust the “wire feed speed” control knob on the spool gun for welding current.


Operate the torch trigger and welding can now be carried out.

Please Note:

The spool gun option can be used in standard and pulse welding modes along with all material choices.

The image right shows the configuration of the 9 pin control socket when used with the spool gun.

Optional Spool Gun



MAINTENANCE



The following operation requires sufficient professional knowledge on electrical/electronic aspects and comprehensive safety knowledge.

Make sure the input cable of the machine is disconnected from the electricity supply and wait for 5 minutes before removing the machine covers.

In order to guarantee that the arc welding machine works efficiently and safely, it must be maintained regularly. Operators should understand the maintenance methods and be conversant with operating arc welding machines. This guide should enable customers to carry out simple examination and safeguarding by themselves, so as to reduce the fault rate and repair times of the arc welding machine, and so lengthen service life of the welding machine.

Period

Maintenance item

Daily examination	• Check the condition of the machine, mains cables, welding cables and connections • Check for any warnings LEDs and machine operation
Monthly examination	• Disconnect from the mains supply and wait for at least 5 minutes before removing the cover • Check internal connections and tighten if required • Clean the inside of the machine with a soft brush and vacuum cleaner • Take care not to remove any cables or cause damage to components • Ensure that ventilation grills are clear • Carefully replace the covers and test the unit This work should be carried out by a suitably qualified competent person
Yearly examination	• Carry out an annual service to include safety check in accordance with the manufacturers standard (EN 60974-1) This work should be carried out by a suitably qualified competent person

⇒ **Ensure the power is disconnected before working on the machine.**

⇒ **Always wait 5 minutes after power switch off before opening the case.**

SERVICE SCHEDULE RECORD

Date	Type of service and work carried out	Serviced by	Due date for next check

TROUBLESHOOTING



The following operation requires sufficient professional knowledge on electrical/electronic aspects and comprehensive safety knowledge.

Make sure the input cable of the machine is disconnected from the electricity supply and wait for 5 minutes before removing the machine covers.

Before arc welding machines are dispatched from the factory, they have already been checked thoroughly. The machine should not be tampered with or altered. Maintenance must be carried out carefully. If any wire becomes loose or is misplaced, it maybe potentially dangerous to the user!

Only professional maintenance personnel should repair the machine!

Ensure the power is disconnected before working on the machine. Always wait 5 minutes after power switch off before removing the panels.

Description of fault	Possible cause
The digital display is OFF and the fan is not functioning	The primary supply voltage has not been switched ON or input fuse has blown
	The welding power source input switch is switched OFF
	Loose connections internally
The digital display is ON but the fan is not running	The machine fan blades may be jammed
	The machine fan may not be functional
	Check the wiring and the supply voltage to the fan
Wire feed motor does not rotate when the MIG torch trigger switch is depressed	Check wire feed speed, to ensure its not set to zero
	Check supply to wire feed motor
	Possible motor PCB fault
Output current reduces when welding	Poor work lead connection to the work piece
TIG electrode melts when arc is struck	TIG torch is connected to the (+) VE terminal
No gas flow when the MIG torch trigger switch is depressed	Empty gas cylinder
	Gas regulator is turned off
	Gas hose is blocked or cut
	Torch trigger switch lead is disconnected or switch/lead is faulty
Difficult to ignite the arc	The welding voltage is too low or the wire feed speed is set too high
The electrode holder becomes very hot	The rated current of the electrode holder is smaller than its actual working current, replace it with a higher rated current capacity
Excessive spatter in MMA welding	The output polarity connection is incorrect, exchange the polarity
Other malfunction	Contact your supplier
Overheat error code lights up	Let the machine cool, it will automatically start again
	Insufficient cooling air
	Cooling fan is not running
Wire continues to feed through when the MIG torch switch is released	The trigger mode switch is set to 4T rather than 2T
	Faulty MIG torch switch
Machine error codes	See the following troubleshooting page for further detail on error codes (page 45)

ERROR CODES



The following operation requires sufficient professional knowledge on electrical/electronic aspects and comprehensive safety knowledge.

Make sure the input cable of the machine is disconnected from the electricity supply and wait for 5 minutes before removing the machine covers.

Before arc welding machines are dispatched from the factory, they have already been checked thoroughly. The machine should not be tampered with or altered. Maintenance must be carried out carefully. If any wire becomes loose or is misplaced, it maybe potentially dangerous to the user!

Only professional maintenance personnel should repair the machine!

Ensure the power is disconnected before working on the machine. Always wait 5 minutes after power switch off before removing the panels.


Error Type	Error code	Description	Lamp status
Thermal relay	E01	Over-heating (1st thermal relay)	Yellow lamp (thermal protection) always on
	E02	Over-heating (2nd thermal relay)	Yellow lamp (thermal protection) always on
	E03	Over-heating (3rd thermal relay)	Yellow lamp (thermal protection) always on
	E04	Over-heating (4th thermal relay)	Yellow lamp (thermal protection) always on
	E09	Over-heating (Program in default)	Yellow lamp (thermal protection) always on
Welding machine	E10	Phase loss	Yellow lamp (thermal protection) always on
	E11	No water	Yellow lamp (lack of coolant) always on
	E12	No gas	Red lamp always on
	E13	Under voltage	Yellow lamp (thermal protection) always on
	E14	Over voltage	Yellow lamp (thermal protection) always on
	E15	Over current	Yellow lamp (thermal protection) always on
	E16	Wire feeder over load	-
Switch	E20	Button fault on operating panel when switch on the machine	Yellow lamp (thermal protection) always on
	E21	Other faults on operating panel when switch on the machine	Yellow lamp (thermal protection) always on
	E22	Torch fault when switch on the machine	Yellow lamp (thermal protection) always on
	E23	Torch fault during normal working process	Yellow lamp (thermal protection) always on
Accessory	E30	Cutting torch disconnection	Red lamp blink
	E31	Water cooler disconnection	Yellow lamp (lack water) always on
Communication	E40	Connection problem between wire feeder and power source	-
	E41	Communication error	-

ELECTRICAL SCHEMATIC



The following operation requires sufficient professional knowledge on electrical/electronic aspects and comprehensive safety knowledge.

Make sure the input cable of the machine is disconnected from the electricity supply and wait for 5 minutes before removing the machine covers.



WEEE disposal

The equipment is manufactured with materials which do not contain any toxic or poisonous materials dangerous to the operator.

When the equipment is scrapped, it should be dismantled separating components according to the type of materials.

Do not dispose of the equipment with normal waste. The European Directive 2002/96/EC and United Kingdom's Directive The Waste Electrical and Electronic Equipment (WEEE) regulations 2013 states that electrical equipment that has reached its end of life must be collected separately and returned to an environmentally compatible recycling facility.

Weld Star has a relevant recycling system which is compliant and registered in the UK with the environment agency. Our registration reference is WEEMM3813AA.

In order to comply with WEEE regulations outside the UK you should contact your supplier.

RoHS Compliance Declaration

We herewith confirm that the above mentioned product does not contain any of the restricted substances as listed in EU Directive 2011/65/EU and the UK directive ROHS Regulations 2012 in concentrations above the limits as specified therein.

UKCA Declaration of Conformity

The manufacturer, or its legal representative Wilkinson Star Limited, declares that the equipment described below is designed and produced according to following UK legislation:

- Electrical equipment safety 2016
- Electromagnetic compatibility (EMC) regulations 2016
- The restrictions of the use of certain hazardous substances in electrical and electronic equipment regulations 2012

And inspected according to following designated standards:

- EN 60 974-1:2018+A1:2019
- EN 60 974-10:2014+A1:2015

Any alteration or change to these machines by any unauthorized person makes this declaration invalid.

Model:

Weld Star WS-M350

Authorised Representative:

Wilkinson Star Limited
Shield Drive
Wardley Industrial Estate
Worsley
Manchester
M28 2WD

Disclaimer:

Please note that this confirmation is given to the best of our present knowledge and belief.

Nothing herein represents and/or may be interpreted as warranty within the meaning of the applicable warranty law.



EC DECLARATION OF CONFORMITY

The manufacturer, or its legal representative **Wilkinson Star Limited**, declares that the equipment described below is designed and produced according to following EU Directives:

- Low Voltage Directive (LVD), No.: 2014/35/EU
- Electromagnetic compatibility (EMC) Directive, No.: 2014/30/EU

And inspected according to following

EU - Norms:

- EN 60 974-1:2012
- EN 60 974-10:2014+A1

Any alteration or change to these machines by any unauthorized person makes this Declaration invalid.

Wilkinson Star model

Weld Star WS-350P

Authorised Representative

Wilkinson Star Limited
Shield Drive,
Wardley Industrial Estate
Worsley
Manchester
M28 2WD

Signature

Dr John A Wilkinson OBE

Position Chairman

Date



Company stamp

STATEMENT OF WARRANTY

All Weld Star welding, plasma multi-process machines sold through our partner Wilkinson Star Ltd within the United Kingdom, Ireland and Europe shall be warranted to the original owner, non transferable, against failure due to defective materials or production.

The warranty period is 5 years following the date of purchase.

We recommend you register your product within 28 days of purchase via the registration page via the Weld Star product website www.weldstar.uk

The original invoice is documentation for the standard warranty period.

The warranty period is based on a single shift pattern.

Defective units shall be repaired or replaced by the company at our workshop.

The company may opt to refund the purchase price (less any costs and depreciation due to use and wear).

The company reserves the right to alter the warranty conditions at any time with effect for the future.

A prerequisite for the full warranty is that products are operated in accordance with the operating instructions supplied, observing the relevant installation and any legal requirements recommendations and guidelines and carrying out the maintenance instructions shown in the Weld Star operator manual. This should only be carried out by a suitably qualified competent person.

In the unlikely event of a problem, this should be reported to the Wilkinson Star Ltd technical support team to review the claim.

The customer has no claim to loan or replacement products whilst repairs are being performed.

The following falls outside the scope of the warranty:

- Defects due to natural wear and tear
- Failure to observe the operating and maintenance instructions
- Connection to an incorrect or faulty mains supply
- Overloading during use
- Any modifications that are made to the product without the prior written consent
- Software errors due incorrect operation
- Any repairs that are carried out using non-approved spare parts
- Any transport or storage damage
- Direct or indirect damage as well as any loss of earnings are not covered under the warranty
- External damage such as fire or damage due to natural causes e.g. flooding

NOTE:

Under the terms of the warranty, welding torches, their consumable parts, wire feed unit drive rolls and guide tubes, work return cables and clamps, electrode holders, connection and extension cables, mains and control leads, plugs, wheels, coolant etc. are covered with a 3 month warranty.

Wilkinson Star Ltd shall in no event be responsible for any third party expenses or expenses/costs or any indirect or consequential expenses/costs.

Wilkinson Star Ltd will submit an invoice for any repair work performed outside the scope of the warranty. A quotation for any non warranty will be raised prior to any repairs being carried out.

The decision about repair or replacement of the defective part(s) is made by Wilkinson Star Ltd. The replaced part(s) remain(s) Wilkinson Star Ltd property.

Warranty extends only to the machine, its accessories and parts contained inside.

No other warranty is expressed or implied.

No warranty is expressed or implied in regards to the fitness of the product for any particular application or use.

OPTIONS AND ACCESSORIES

Part Number	Description
----	MIG torch options for air/water cooled options
T360-3	Titanium 360 MIG Torch Air Cooled 3mtr Euro
T360-4	Titanium 360 MIG Torch Air Cooled 4mtr Euro
T360-5	Titanium 360 MIG Torch Air Cooled 5mtr Euro
T501-3	Titanium 501 MIG Torch Water Cooled 3mtr Euro
T501-4	Titanium 501 MIG Torch Water Cooled 4mtr Euro
T501-5	Titanium 501 MIG Torch Water Cooled 5mtr Euro
WS-SP250-6	Spool Gun
WS-T4	4 Wheel Trolley
WS-WC	Water Cooler (Used with 4 Wheel Trolley)
WS-TD	Toolbox (Used with 4 Wheel Trolley for Air Cooled Package)
WCS50-5	Welding Cable Set 50mm (MMA) 5m
WCS70-5	Welding Cable Set 70mm (MMA) 5m
WC-5-05	Electrode Holder and Lead 50mm 5m
WC-7-05	Electrode Holder and Lead 70mm 5m
EC-5-05	Work Return Lead 50mm and Clamp 5m
EC-7-05	Work Return Lead 70mm and Clamp 5m
TIG-104	WP26 Style TIG Torch 4m
CP3550	Cable Plug 35-50mm
CP5070	Cable Plug 50-70mm
SSARG2G	Single Stage 2 Gauge Argon Regulator
For feed roll part numbers and information, go to page 25.	

MEMORY STORAGE

Use the below section to list your stored program channel numbers that you have created and stored for specific welding tasks.

Memory No	MMA, MIG or TIG	Job number or Description of welding job
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		

NOTES

[illegible]

WELD STAR | INFINIUM

Wilkinson Star Limited

Shield Drive
Wardley Industrial Estate
Worsley
Manchester
M28 2WD

+44(0)161 793 8127

wilkinsonstar247.com

50 / A family business
engineered through
generations **since 1971**

April 2023 Issue 3

E&OE